## 34 LAND CRUISER (LHD) Power Source Headlight Beam Level Control 3 2 Multiplex Communication System<1–14> 10A HEAD LH-LWR H 1 Headlight Beam Level Control Actuator LH H 2 Headlight Beam Level Control Actuator RH H19 Headlight Beam Level Control SW GND F37 Fusible Link Block 20 IF2 11 IF2 J25 Junction Battery Front Right Side of Fender Apron Set Bolt of Cowl Side J/B LH