(c)

5. Engine Proper

Cylinder Head Cover

For the purpose of installing the exhaust fuel addition injector, the following changes have been made to the cylinder head:


- (a) Addition of a hole for installing the exhaust fuel addition injector and an oil seal
- (b) Addition of an oil seal for the fuel return outlet for main injector
- (c) Addition of a fuel relief passage, which is used in case of fuel leakage from the exhaust fuel addition injector.
- Change in the seal line of the cylinder head cover gasket to accommodate the addition of the exhaust fuel addition injector


(a)

258AE05

Cylinder Head

 Addition of a hole for installing the exhaust fuel addition injector





258AE06

Service Tip

To distinguish from the gasket for the 1CD-FTV engine without D-CAT, the gasket for the 1CD-FTV engine with D-CAT has a yellow mark. This prevents the wrong gasket from being installed.

