CAUTION:

FOR ALL OF VEHICLES PRECAUTION

INOKJ-01

1. FOR VEHICLES EQUIPPED WITH A CATALYTIC CONVERTER

If large amounts of unburned gasoline flow into the converter, it may overheat and create a fire hazard. To prevent this, observe the following precautions and explain them to your customer.

- (a) Use only unleaded gasoline.
- (b) Avoid prolonged idling.
 - Avoid idling the engine for more than 20 minutes.
- (c) Avoid spark jump test.
 - (1) Perform spark jump tests only when absolutely necessary. Perform this test as rapidly as possible.
 - (2) While testing, never race the engine.
- (d) Avoid prolonged engine compression measurement.
 - Engine compression tests must be done as rapidly as possible.
- (e) Do not run engine when fuel tank is nearly empty.
 - This may cause the engine to misfire and create an extra load on the converter.
- (f) Avoid coasting with ignition turned off and prolonged braking.
- (g) Do not dispose of used catalyst with gasoline or oil contaminated parts.

2. IF VEHICLE IS EQUIPPED WITH MOBILE COMMUNICATION SYSTEM

For vehicles with mobile communication systems such as two-way radios and cellular telephones, observe the following precautions.

- (1) Install the antenna as far away as possible from the ECU and sensors of the vehicle's electronic system.
- (2) Install the antenna feeder at least 20 cm (7.87 in.) away from the ECU and sensors of the vehicle's electronics systems. For details about ECU and sensors locations, refer to the applicable component's section .
- (3) Avoid winding the antenna feeder together with the other wiring, as much as possible, and also avoid running the antenna feeder parallel with other wire harnesses.
- (4) Check that the antenna and feeder are correctly adjusted.
- (5) Do not install powerful mobile communications system.

3. FOR USING HAND-HELD TESTER

CAUTION:

Observe the following for safety reasons:

- Before using the hand-held tester, read its user manual throughly.
- Be sure to route all cables securely when driving with the hand-held tester connected to the vehicle. (I.e., keep cables away from feet, pedals, steering wheel and shift lever.)
- Two persons are required when test-driving with the hand-held tester: one person to drive the vehicle and another to operate the hand-held tester.