BO1V2-01

REMOVAL

- 1. w/[Roof[Rail: REMOVE[ROOF[RAIL[(See[page[BO-227)])]]
- 2. w/[Roof[Rack: REMOVE[ROOF[RACK[See[page[BO-228]
- 3. REMOVE NO.2 ROOF DRIP SIDE FINISH CENTER MOULDING
- 4. REMOVE ROOF DRIP SIDE FINISH MOULDING

Using a moulding remover, remove the roof drip side finish moulding.

NOTICE:

- Do not damage the body.
- Do not remove the No.2 roof drip side finish moulding clip.
- When the clip comes off, replace it with a new one.

HINT:

Tape the moulding remover tip before use.

