BO1TW–01

REASSEMBLY

Reassembly is in the reverse order of disassembly (See page BO–16).