MODEL CODE

HZB50 R - Z E M R S Q 5

7

	BASIC N	MODEL CODE	
1	CODE	ENGINE	WHEEL BASE
	RZB40	3RZ-FE	Short
	RZB50		Long
	BB42	14B	Short
	BB50	15B-FT	Long
		15B-FTE	
	BB58		
	BB59		Super Long
	BZB40	1BZ-FPE	Short
	BZB50		Long
	HZB50	1HZ	

	STEERING WHEEL POSITION	
2	L: Left-Hand Drive R: Right-Hand Drive	
	K . Rigin-Hallu Diive	

	ROOF TYPE	
3	B : Standard Roof	
	Z: High Roof	

	SEATING CAPACITY	
4	C:17 E:19, 20, 21 G:30 R:26	

	GEAR SHIFT TYPE	
5	F: 6-Speed Manual, Floor M: 5-Speed Manual, Floor	

GRADE
N: DX R: Standard (Without Air Conditioner) S: Standard (With Air Conditioner) Q: EX

ENGINE SPECIFICA	TION
C:LPG	
K : EFI Gasoline	
S : Diesel	

W: Diesel, Turbocharger Z: EFI Diesel, Turbocharger

PESTINATION Q: Australia V: G.C.C. (Gulf Cooperation Council) Counries Blank: General Countries



5