
DI88S-06

4. No correspondii	ng screen	displayed	when '	"Audio"	or '	'Informa–
tion" switch į	oressed.					



LAND CRUISER (W/G) SUP (RM1072E)

Replace the multi display.