
Connector Joining Wire Harness and Wire Harness



Code	Joining Wire Harness and Wire Harness (Connector Location)
BU2	Floor No.2 Wire and Front Seat RH Wire (Front Side Under the Front Passenger's Seat)
BU3	