SA174–02

INSPECTION

INSPECT SHOCK ABSORBER

Compress and extend the shock absorber rod and check that there is no abnormal resistance or unusual operation sounds. If there is any abnormality, replace the shock absorber with a new one.

NOTICE:

w/o AHC System:

When disposing the shock absorber, see DISPOSAL on .

SA0627