49 LAND CRUISER (LHD) Power Source Audio System (Built-in Amplifier) 2 3 4 C 6 CD Automatic Changer MUTE GND SGND CDR-CDL-CDL+ TX-CDR+ 5 IG1 ACC (*7, *8) I26 Ignition SW 4(1B) 39 (2E) 30A AMP AM1 5**B**) 12**B** ACC ACC MUTE R 2(A), R 3(B), R 4(C) Radio and Player (Except 2UZ-FE) FR+ RR-GND ACC 2(A) 1**(**A) 5(A) 7**(**A) 1 (1C) 1 If2 2 If2 38 ID5 34 IQ3 33 IQ3 3 If2 1 le1 36 IQ3 (87) ACC CUT 3 BB3 2 BB3 3 BE3 2 BE3 120A J/B NO. 3 IC3 1 IW3 120A 120A MAIN F38(B), Link Blo J/B NO. 2 52 (3Q) , F39(C) (*3) P (%3) LG 140A Engine Control and Fuel Tank (*1, *2) (84) Changeover System <8-3> T19 Tweeter LH T20 Tweeter RH (*8) (*3) (*3) (*3) B-R (Diesel) * 1 : 2 Speaker * 2 : 4 Speaker * 3 : 6 Speaker * 4:4,6 Speaker F23 Front Door F24 Front Door R24 Rear Door R25 Rear Door * 5 : Bench Seat * 6 : Separate Seat Speaker LH Speaker RH Speaker LH Speaker RH * 7 : 2UZ-FE A/T 7 Set Bolt of Cowl Side J/B LH Rear Side Under the BL * 8 : 2UZ-FE M/T Front Seat RH