
DIAXS-01

Jam protection limit / pulse switch circuit on rear left door

CIRCUIT DESCRIPTION

The rear LH power window switch receives the power window switch signal from the switch to operate the power window motor.

WIRING DIAGRAM



INSPECTION PROCEDURE

1 Check jam protection jimit juse switch (See page BE-51).

NG□

Replace power window motor.

OK

2 Check wire harness and connector between power window motor and power window witch (See page N-38).

NG

Repair or replace wire harness or connector.

OK

Replace Power window switch.