Position of Parts in Instrument Panel [LHD] (J27 J30 M5 M4 J6 J7 * 2:w/o VSC * 7:A/T * 16:1HZ * 25:M/T J24

J8

J9

(J10)

1 Junction Connector

(J16

- 2 Junction Connector
- 3 Junction Connector
- 4 Junction Connector
- J 5 Junction Connector
- 6 Junction Connector
- J 7 Junction Connector
- J 8 Junction Connector
- J 9 Junction Connector
- J 10 Junction Connector
- J 11 Junction Connector
- J 12 Junction Connector
- J 13 Junction Connector
- J 14 Junction Connector
- J 15 Junction Connector
- J 16 Junction Connector
- J 17 Junction Connector

- J 18 Junction Connector
- J 19 Junction Connector
- J 24 Junction Connector
- J 25 Junction Connector
- J 26 Junction Connector
- J 27 Junction Connector J 28 Junction Connector
- J 29 Junction Connector
- J 30 Junction Connector
- M 4 Multi-Display M 5 Multi-Display
- O 2 O/D Main SW
- P 3 Power Outlet (Front)
- P 6 Pre-Heating Timer