RS0NK–07

INSPECTION

1. **Vehicle not involved in collision:**
    INSPECT SUPPLEMENTAL RESTRAINT SYSTEM

Do a diagnostic system check (See page DI–432).

2. **Vehicle involved in collision and airbag is not deployed:**
    INSPECT SUPPLEMENTAL RESTRAINT SYSTEM

Do a diagnostic system check (See page DI–432).

3. **Vehicle involved in collision and airbag is deployed:**
    INSPECT SUPPLEMENTAL RESTRAINT SYSTEM

Replace the side and curtain shield airbag sensor assembly (See page DI–432).