## 28 LAND CRUISER (LHD) Power Source Remote Control Mirror (w/o Driving Position Memory) 3 2 (\*1) R 9 Remote Control Mirror SW (\*2, \*3) ACC /Up WS ( 13 IF2 I26 Ignition SW LH Q LH γ MLH MRH MLV MRV M+ 39 (2E) 44(2Q) GR(\*1) 4 IV1 R10 Remote Control Mirror SW 15 IF2 4 IF2 16 IF2 5 IF2 19 IF2 50 (3Q) 22 IF2 11 IF2 D J27 Junction Connector (\$2) 8**(**3J**)** 31 (3Q) 32**(**3Q) 52 (3Q) 1(3C) SB 120A J/B NO. 3 120A J/B NO. 2 J25 Junction ), F39(C) e Link Blo 40 (2E) 66 30 3 IV1 47 2Q 3 4 (2Q) 57 (3Q) 5(2Q) (\*4) 11 (2J) 4(2J) 14(2J) 11 (3J) 13**(**2J**)** 10**(**3J) (° 2 ≥ \* 1 : w/ Retractor (Diesel) \* 2 : 2UZ-FE A/T MH MV \* 3 : 2UZ-FE M/T МН MV \* 4 : Except 2UZ-FE $\bigcirc$ M B-R (\*2, \*3) 7 Set Bolt of Cowl Side J/B LH Set Bolt of Cowl Side J/B LH R48 Remote Control Mirror LH R49 Remote Control Mirror RH