348

## 11 LAND CRUISER (RHD) Power Source Emission Control (1HZ) 2 3 4 25 (6D) 24 (6D) 23 (6D) 26 (6D) 17 (4D) W-R Glow Plug Relay<6-3 ST2 I26 Ignition SW P 1 Pick-Up Sensor 9 (1B) 21 (2D) 39 **2E** 19**(**2D) 37 (2E) 4(3E) 7 (3Q) 8 lh1 F12 Fuel Cut C15(A), C18(D) Combination Meter 1**(**B) Valve Controller STA BATT SREL VEGR IG E21(A), E22(B) Emission Control ECU IG1 NO. 2 Relay IMMO THW TCV2 18(A) 17(A) 12(A) 14**B** 6**B** 13**(**B) 14(A) 4(A) 16(A) 3**(**A) 5**B** 8**B** 1(10) 3 lh1 2 lh1 3 If4 4**6**C) 5 (6C) 120A J/B NO. 2 VSV (A/C Idle-<55-6> 2 If4 MAIN E2 T24 Throttle Position Battery Battery Sensor and Timing Control Valve L-R R-L Set Bolt of Cowl Side J/B LH Rear Bank of Left \( \bar{\cup} \) EC