## **IDLE SPEED**

## **INSPECTION**

EM0TJ-0

## 1. INITIAL CONDITIONS

- (a) Engine at normal operating temperature
- (b) Air cleaner installed
- (c) All pipes and hoses of air induction system connected
- (d) All accessories switched OFF
- (e) All vacuum lines properly connected

## HINT:

All vacuum hoses should be properly connected.

- (f) EFI system wiring connectors fully plugged
- (g) Ignition timing set correctly
- (h) Transmission in neutral position
- (i) Air conditioning switched OFF
- 2. CONNECT TACHOMETER

(See page EM-11)

- 3. INSPECT IDLE SPEED
- (a) Race the engine speed at 2,500 rpm for approx. 90 seconds.
- (b) Check the idle speed.

Idle speed: 700  $\pm$  50 rpm

If the idle speed is not as specified, check the air intake system.

4. DISCONNECT TACHOMETER