## **INSTALLATION**

RS0D1-01

- 1. INSTALL SPIRAL CABLE (See page SR-24)
- 2. INSTALL[UPPER[AND[LOWER[COLUMN[COVERS[See[page[\$R-24]]]]]
- 3. INSTALL[\$TEERING[WHEEL[(See[page[\$R-24)])]
- 4. INSTALL STEERING WHEEL PAD See page R-24)