DI897-03

## 19. Navigation screen cannot change to the hight mode color.

INSPECTION PROCEDURE	
1	Check[the[setting.[(Is[it[set[to[Day[Mode[in[screen[adjustment?)
	Yes Normal.
No	
2	Check[if[the[screen[is[dimmed[at[hight.[With[the[light[control[switch[ON,[do[all screens[except[the[havigation[screen[appear[in[Night[Mode?)
	NG  Go[to[step[5.
ОК	
3[]	Does[the[beep[sound[by[operating[switches[on[the[navigation[screen?
	OK Replace the navigation ECU.
NG	
4[]	Check[]*AVC-LAN@communication@ircuit**([See@page@I-1@4).
	NG Replace or repair AVC-LAN circuit.
ОК	
Repla	ice the navigation ECU.

5 Check the multi display.

**CHECK:** 

Check terminal TAIL.

<u>OK:</u>

TAIL: See "Multi Display" of "TERMINAL OF ECU".

OK Replace the multi display.

NG

Replace or repair wire harness.