ENGINE[IMMOBILISER[SYSTEM] HOW[TO[PROCEED[WITH[TROUBLESHOOTING]

DIB0I-01

Troubleshoot in accordance with the procedure on the following pages.

