[Instrument Panel]
(LHD1)

J/B No.5   AHC Main Relay   Suspension Control ECU   **J/B No.4**

Double Lock Control Relay

VGRS ECU

Auto Wiper ECU

Tilt and Telescopic ECU

Body ECU

Cowl Side J/B LH

ABS & BA & TRC & VSC ECU (*1)
ABS ECU (*2)

* 1:w/ VSC
* 2:w/o VSC

Gateway ECU

A/C Control Assembly

Transponder Key Amplifier   Airbag Sensor Assembly   Shift Lock Control ECU

(LHD2)

* 3:w/ Front Diff. Lock
* 4:w/o Front Diff. Lock
* 5:w/ Center Diff. Lock
* 6:w/o Center Diff. Lock
* 7:A/T Except 1HZ
* 8:M/T Except 1HZ
* 9:1HZ

Auto Antenna Control Relay   Transponder Key Computer   Theft Deterrent ECU

Front/Rear Diff. Lock Control ECU (*3)
Rear Diff. Lock Control ECU (*4)

J/B No.7

Center Diff. Lock Control Relay (*5)
ADD Control Relay (*6)

Cowl Side J/B RH

Engine ECU (*8)
Engine and ECT ECU (*7)
Emission Control ECU (*9)

J/B No.6   Blower LO Relay   Blower ME Relay   Blower HI Relay   Viscous Heater Amplifier