

Spacecraft and Aircraft Dynamics

Matthew M. Peet
Illinois Institute of Technology

Lecture 12: Lateral Dynamics and Summary

Aircraft Dynamics

Lecture 12

In this Lecture we will cover:

Lateral Dynamics:

- Finding dimensional coefficients from non-dimensional coefficients
- Eigenvalue Analysis
- Approximate modal behavior
 - ▶ Spiral mode
 - ▶ Roll Mode
 - ▶ Dutch Roll mode

Review: Lateral Dynamics

Combined Terms

$$\Delta\dot{v} = \Delta\phi g \cos\theta_0 - u_0\Delta r + Y_v\Delta v + Y_p\Delta p + Y_r\Delta r + Y_{\delta_r}\delta_r$$

$$\begin{aligned}\Delta\dot{p} = & \frac{I_{zz}}{I_{xx}I_{zz} - I_{xz}^2} (L_v\Delta v + L_p\Delta p + L_r\Delta r + L_{\delta_r}\delta_r + L_{\delta_a}\delta_a) \\ & + \frac{I_{xz}I_{xx}}{I_{xx}I_{zz} - I_{xz}^2} (N_v\Delta v + N_p\Delta p + N_r\Delta r + N_{\delta_r}\delta_r + N_{\delta_a}\delta_a)\end{aligned}$$

$$\begin{aligned}\Delta\dot{r} = & \frac{I_{xz}I_{zz}}{I_{xx}I_{zz} - I_{xz}^2} (L_v\Delta v + L_p\Delta p + L_r\Delta r + L_{\delta_r}\delta_r + L_{\delta_a}\delta_a) \\ & + \frac{I_{xx}}{I_{xx}I_{zz} - I_{xz}^2} (N_v\Delta v + N_p\Delta p + N_r\Delta r + N_{\delta_r}\delta_r + N_{\delta_a}\delta_a)\end{aligned}$$

$$\Delta\dot{\phi} = \Delta p + \Delta r \tan\theta_0$$

Force Coefficients

Force/Moment Coefficients can be found in Table 3.6 of Nelson

TABLE 3.6

Summary of lateral directional derivatives

$$Y_\beta = \frac{QSC_{y\beta}}{m} \text{ (ft/s}^2\text{) or (m/s}^2\text{)}$$

$$N_\beta = \frac{QSbC_{n\beta}}{I_z} \text{ (s}^{-2}\text{)}$$

$$L_\beta = \frac{QSbC_{l\beta}}{I_x} \text{ (s}^{-2}\text{)}$$

$$Y_p = \frac{QSbC_{yp}}{2mu_0} \text{ (ft/s) (m/s)}$$

$$N_p = \frac{QSb^2C_{np}}{2I_zu_0} \text{ (s}^{-1}\text{)}$$

$$L_p = \frac{QSb^2C_{lp}}{2I_xu_0} \text{ (s}^{-1}\text{)}$$

$$Y_r = \frac{QSbC_{yr}}{2mu_0} \text{ (ft/s) or (m/s)}$$

$$N_r = \frac{QSb^2C_{nr}}{2I_zu_0} \text{ (s}^{-1}\text{)}$$

$$L_r = \frac{QSb^2C_{lr}}{2I_xu_0} \text{ (s}^{-1}\text{)}$$

$$Y_{\delta a} = \frac{QSC_{y\delta a}}{m} \text{ (ft/s}^2\text{) or (m/s}^2\text{)}$$

$$Y_{\delta r} = \frac{QSC_{y\delta r}}{m} \text{ (ft/s}^2\text{) or (m/s}^2\text{)}$$

$$N_{\delta a} = \frac{QSbC_{n\delta a}}{I_z} \text{ (s}^{-2}\text{)}$$

$$N_{\delta r} = \frac{QSbC_{n\delta r}}{I_z} \text{ (s}^{-2}\text{)}$$

$$L_{\delta a} = \frac{QSbC_{l\delta a}}{I_x} \text{ (s}^{-2}\text{)}$$

$$L_{\delta r} = \frac{QSbC_{l\delta r}}{I_x} \text{ (s}^{-2}\text{)}$$

Nondimensional Force Coefficients

Nondimensional Force/Moment Coefficients can be found in Table 3.4 of Nelson

TABLE 3.4

Equations for estimating the lateral stability coefficients

	Y-force derivatives	Yawing moment derivatives	Rolling moment derivatives
β	$C_{y_\beta} = -\eta \frac{S_v}{S} C_{L_{a_0}} \left(1 + \frac{d\sigma}{d\beta} \right)$	$C_{n_\beta} = C_{n_{\beta_{ref}}} + \eta_v V_v C_{L_{a_0}} \left(1 + \frac{d\sigma}{d\beta} \right)$	$C_{l_\beta} = \left(\frac{C_{l_\beta}}{\Gamma} \right) \Gamma + \Delta C_{l_\beta}$ (see Figure 3.11)
p	$C_{y_p} = C_L \frac{AR + \cos \Lambda}{AR + 4\cos \Lambda} \tan \Lambda$	$C_{n_p} = -\frac{C_L}{8}$	$C_{l_p} = -\frac{C_{L_a}}{12} \frac{1 + 3\lambda}{1 + \lambda}$
r	$C_{y_r} = -2 \left(\frac{l_v}{b} \right) (C_{y_\beta})_{tail}$	$C_{n_r} = -2 \eta_v V_v \left(\frac{l_v}{b} \right) C_{L_{a_0}}$	$C_{l_r} = \frac{C_L}{4} - 2 \frac{l_v}{b} \frac{z_v}{b} C_{y_\beta}_{tail}$
δ_a	0	$C_{n_{\delta_a}} = 2K C_{L_0} C_{l_{\delta_a}}$ (see Figure 3.12)	$C_{l_{\delta_a}} = \frac{2C_{L_a}\tau}{Sb} \int_{y_1}^{y_2} cy dy$
δ_r	$C_{y_{\delta_r}} = \frac{S_v}{S} \tau C_{L_{a_0}}$	$C_{n_{\delta_r}} = -V_v \eta_v \tau C_{L_{a_0}}$	$C_{l_{\delta_r}} = \frac{S_v}{S} \left(\frac{z_v}{b} \right) \tau C_{L_{a_0}}$

AR Aspect ratio

b Wingspan

C_{L_0} Reference lift coefficient

C_{L_a} Airplane lift curve slope

$C_{L_{a_w}}$ Wing lift curve slope

$C_{L_{a_t}}$ Tail lift curve slope

\bar{c} Mean aerodynamic chord

K empirical factor

l_v Distance from center of gravity to vertical tail aerodynamic center

V_v Vertical tail volume ratio

S Wing area

S_v Vertical tail area

z_v Distance from center of pressure of vertical tail to fuselage centerline

Γ Wing dihedral angle

Λ Wing sweep angle

η_v Efficiency factor of the vertical tail

λ Taper ratio (tip chord/root chord)

$\frac{d\sigma}{d\beta}$ Change in sidewash angle with a change in sideslip angle

State-Space

$$\begin{bmatrix} \Delta \dot{v} \\ \Delta \dot{p} \\ \Delta \dot{r} \\ \Delta \dot{\phi} \end{bmatrix} = \begin{bmatrix} Y_v & Y_p & Y_r - u_0 & g \cos \theta_0 \\ \frac{L_v}{I'} + I'_{zx} I_{zz} N_v & \frac{L_p}{I'} + I'_{zx} I_{zz} N_p & \frac{L_r}{I'} + I'_{zx} I_{zz} N_r & 0 \\ \frac{N_v}{I'} + I'_{zx} I_{xx} L_v & \frac{N_p}{I'} + I'_{zx} I_{xx} L_p & \frac{N_r}{I'} + I'_{zx} I_{xx} L_r & 0 \\ 0 & 1 & \tan \theta_0 & 0 \end{bmatrix} \begin{bmatrix} \Delta v \\ \Delta p \\ \Delta r \\ \Delta \phi \end{bmatrix}$$

$$+ \begin{bmatrix} Y_{\delta_r} & Y_{\delta_a} \\ \frac{L_{\delta_r}}{I'} + I'_{zx} I_{zz} N_{\delta_r} & \frac{L_{\delta_a}}{I'} + I'_{zx} I_{zz} N_{\delta_a} \\ \frac{L_{\delta_r}}{I'} + I'_{zx} I_{zz} N_{\delta_r} & \frac{L_{\delta_a}}{I'} + I'_{zx} I_{zz} N_{\delta_a} \\ 0 & 0 \end{bmatrix} \begin{bmatrix} \Delta \delta_r \\ \Delta \delta_a \end{bmatrix}$$

$$I' := 1 - \frac{I_{zx}^2}{I_{xx} I_{zz}}, \quad I'_{zx} := \frac{I_{zx}}{I_x I_z I'}$$

State-Space

Example: Uncontrolled Motion

C172: $V_0 = 132kt$, 5000 ft.

$$\begin{bmatrix} \Delta\dot{\beta} \\ \Delta\dot{p} \\ \Delta\dot{r} \\ \Delta\dot{\phi} \end{bmatrix} = \begin{bmatrix} -.1473 & -.0014 & -.9918 & .1470 \\ -28.749 & -12.4092 & 2.5346 & 0 \\ 10.119 & -.3817 & -1.2597 & 0 \\ 0 & 1 & 0 & 0 \end{bmatrix} \begin{bmatrix} \Delta\beta \\ \Delta p \\ \Delta r \\ \Delta\phi \end{bmatrix}$$

We use $\Delta\beta \cong \frac{\Delta v}{u_0}$.

State-Space

Example: Uncontrolled Motion

Using the Matlab command $[u, V] = \text{eigs}(A_{lat})$, we find the eigenvalues as

Spiral Mode

$$\lambda_1 = -0.011$$

Exponential decay, not oscillating.

Roll Mode

$$\lambda_2 = -12.43$$

Exponential decay, not oscillating.

Dutch Roll Mode

$$\lambda_{3,4} = -.686 \pm 3.306i$$

Exponential decay, oscillating.

State-Space

Spiral Mode

Spiral Mode

$$\lambda_1 = -0.011$$

with Eigenvector

$$\nu_1 = \begin{bmatrix} .0176 \\ -.011 \\ .1458 \\ 1 \end{bmatrix}$$

Natural Frequency: N/A

Damping Ratio: $d = 0.011$


Period: N/A

Half-Life: $\gamma = 91s$

Slow convergence in coupled ϕ and r .

State-Space

Spiral Mode



State-Space

Spiral Mode

State-Space

Roll Mode

Roll Mode

$$\lambda_2 = -12.43$$

with Eigenvector

$$\nu_2 = \begin{bmatrix} .0036 \\ 1 \\ .0309 \\ -.0804 \end{bmatrix}$$

Natural Frequency: N/A

Damping Ratio: $d = -12.43$



Period: N/A

Half-Life: $\gamma = .08s$

Fast convergence in roll rate, p .

State-Space

Roll Mode



State-Space

Roll Mode: Example

State-Space

Dutch Roll Mode

Dutch Roll Mode

$$\lambda_{3,4} = -.686 \pm 3.306i \quad \omega_{DR} = 3.4 \quad d_{DR} = .2$$

and Eigenvectors

$$v_{3,4} = \begin{bmatrix} .0954 \\ -.2150 \\ .7569 \\ -.1357 \end{bmatrix} \pm \begin{bmatrix} .2175 \\ .5127 \\ .1856 \\ .0932 \end{bmatrix} i$$

Natural Frequency: $\omega_n = 3.4 \text{ rad/s}$

Damping Ratio: $d = .2$

Period: $\tau = 1.848 \text{ s}$


Half-Life: $\gamma = 1.01 \text{ s}$

Complex coupling in β , p , r and ϕ .

- Exacerbated by high-mounted wings (Counter with anhedral)
- Swept wings and dihedral contribute
- Most commonly compensated mode.
- Yaw damper is typical response.

State-Space

Dutch Roll Mode



State-Space

Dutch Roll Mode: Example

State-Space

Modal Approximations

Now that we know that lateral dynamics have three modes:

- Spiral Mode
- Roll Mode
- Dutch Roll Mode

Spiral Mode:

- Motion in r and β
- Set $\Delta\dot{p} = \Delta p = 0$ and solve for $\Delta\beta$.
- Use EOM for dynamics of Δr

Roll Mode:

- motion only in roll, Δp

Dutch Roll Mode:

- Coupled motion in β, r

Spiral Mode Approximation

By setting $\Delta\dot{p} = \Delta p = 0$ and solving for β , we get

$$\Delta\beta = \frac{L_r}{L_\beta}\Delta r$$

Plug that into EOM for Δr and we get

$$\Delta\dot{r} = -\frac{L_r N_\beta - L_\beta N_r}{L_\beta}\Delta r.$$

Which obviously has

$$\lambda_1 = -\frac{L_r N_\beta - L_\beta N_r}{L_\beta}$$

- L_β is negative for dihedral.
- N_r is negative for a yaw-damper.

Spiral Mode Approximations

Examples: NAVION and C172

NAVION:

Approximate Eigenvalue:

$$\lambda_{roll} = -.144$$

True Eigenvalue:

$$\lambda_{roll} = -.00877$$

C172:

Approximate Eigenvalue:

$$\lambda_{roll} = -.36$$

True Eigenvalue:

$$\lambda_{roll} = -.011$$

Not Encouraging.

Roll Mode Approximation

By ignoring all variables except p , we get the simple dynamics

$$\Delta \dot{p} = L_p \Delta p + L_{\delta_a} \delta_a$$

Which obviously has

$$\lambda_2 = L_p$$

- Typically quite stable.
- If unstable, something is very wrong.

Roll Mode Approximations

Examples: NAVION and C172

NAVION:

Approximate Eigenvalue:

$$L_p = -12.41$$

True Eigenvalue:

$$\lambda_{roll} = -12.43$$

C172:

Approximate Eigenvalue:

$$L_p = -8.4$$

True Eigenvalue:

$$\lambda_{roll} = -8.435$$

So, generally good agreement.

Dutch Roll Mode Approximation

If dihedral (L_β) is small, then we can neglect rolling motion

- L_β hurts spiral mode but helps Dutch Roll.

$$\Delta\dot{\beta} = \frac{Y_\beta}{u_0}\Delta\beta + \left(\frac{Y_r}{u_0} - 1\right)\Delta r + \frac{Y_{\delta_a}}{u_0}\delta_a + \frac{Y_{\delta_r}}{u_0}\delta_r$$

$$\Delta\dot{r} = N_\beta\Delta\beta + N_r\Delta r + N_{\delta_a}\delta_a + N_{\delta_r}\delta_r$$

- Also assume $\frac{I_{zx}}{I_{zz}}$ is negligible.

Ignoring the inputs, we can write a state-space description as:

$$\begin{bmatrix} \Delta\dot{\beta} \\ \Delta\dot{r} \end{bmatrix} = \begin{bmatrix} \frac{Y_\beta}{u_0} & \left(\frac{Y_r}{u_0} - 1\right) \\ N_\beta & N_r \end{bmatrix} \begin{bmatrix} \Delta\beta \\ \Delta r \end{bmatrix}.$$

Dutch Roll Mode Approximation

Starting with state-space:

$$\begin{bmatrix} \Delta\dot{\beta} \\ \Delta\dot{r} \end{bmatrix} = \begin{bmatrix} \frac{Y_\beta}{u_0} & \left(\frac{Y_r}{u_0} - 1\right) \\ N_\beta & N_r \end{bmatrix} \begin{bmatrix} \Delta\beta \\ \Delta r \end{bmatrix},$$

we find the characteristic equation

$$\det(sI - A) = s^2 - \left(N_r + \frac{Y_\beta}{u_0}\right)s + \left(N_\beta + \frac{Y_\beta N_r}{u_0} - \frac{Y_r N_\beta}{u_0}\right),$$

which yields the approximate formulae:

$$\omega_{DR} = \sqrt{\frac{1}{u_0} (Y_\beta N_r + N_\beta u_0 - N_\beta Y_r)}$$
$$d_{DR} = \frac{N_r + \frac{Y_\beta}{u_0}}{\omega_{DR}}$$

Approximation is generally OK approximation for ω , but not for d .

Dutch Roll Mode Approximations

Example: NAVION

Approximate Period:

$$\omega_{DR} = 2.98s$$

True Period:

$$\omega_{DR} = 2.69s$$

Approximate Damping:

$$d_{DR} = 1.35s$$

True Damping:

$$d_{DR} = 1.42 \text{ rad/s}$$

So, generally good, but not as good. Why?

Conclusion



In this lecture, we covered:

- Eigenvalue analysis of the lateral dynamics
- How to identify
 - ▶ Spiral Mode Eigenvalues/Motion
 - ▶ Roll Mode Eigenvalues/Motion
 - ▶ Dutch Roll Mode Eigenvalues/Motion
- Modal Approximations
 - ▶ Spiral, Roll and Dutch Roll Modes
 - ▶ Formulae for natural frequency
 - ▶ Formulae for damping ratio

Review: Static Stability

Coordinates

- The origin is the center of mass.
- The x -axis points toward the front of the aircraft.
- The z -axis points down.
- The y -axis is perpendicular to the $x - z$ plane.
- Use the “right-hand rule” to define y



Review: Static Stability

Longitudinal Stability

Lift Equation: For α measured from zero lift line.

$$C_L = \left(C_{L\alpha, wf} + \eta \frac{S_t}{S} C_{L\alpha, t} \left(1 - \frac{d\epsilon}{d\alpha} \right) \right) \alpha$$

Review: Static Stability

Longitudinal Stability

Moment Equation:

$$C_m = C_{m0} + C_{m\alpha}\alpha + C_{m\delta_e}$$

Expressions for $C_{m\alpha}$ and $C_{m\delta}$

$$C_{M0,wf} + \eta V_H C_{L\alpha,t} (\varepsilon_0 + i_{wf} - i_t)$$

$$C_{m\alpha} = C_{L\alpha,wf} \left(\frac{X_{CG}}{\bar{c}} - \frac{X_{AC,wf}}{\bar{c}} \right) - \eta V_H C_{L\alpha,t} \left(1 - \frac{d\varepsilon}{d\alpha} \right)$$

$$C_{m\delta_e} = -\eta V_H C_{L\alpha,t} \tau$$

- Stable if $C_{m\alpha} < 0$
- $\alpha_{eq} = -\frac{C_{m0}}{C_{m\alpha}}$
- Neutral point when $C_{m\alpha} = 0$

Review: Static Stability

Directional Stability

$$C_n = C_{n\beta}\beta + C_{n\delta_r}\delta_r$$

where

$$C_{n\delta_r} = -\eta_v V_v C_{L\alpha,v} \tau,$$

- Stable if $C_{n\beta} > 0$
- Use plots/data to find $C_{n\beta}$

Review: Static Stability

Roll Stability

$$C_l = C_{l\beta}\beta + C_{l\delta_a}\delta_a$$

where

$$C_{l\delta_a} \cong 2C_{L\alpha}\tau \frac{y_c}{b}$$

- Stable if $C_{l\beta} < 0$
- Use plots/data to find $C_{l\beta}$

Review

Eigenvalues

$$\lambda = \lambda_R \pm i\lambda_I$$

1. **Natural Frequency:**

$$\omega_n = \sqrt{\lambda_R^2 + \lambda_I^2}$$

2. **Damping Ratio:**

$$d = -\frac{\lambda_R}{\omega_n}$$

3. **Period:**

$$\tau = \frac{2\pi}{\omega_n}$$

4. **Half Life:**

$$\gamma = \frac{.693}{|\lambda_R|}$$

Review

Approximations: Longitudinal Dynamics

Short Period Mode:

$$\lambda_{3,4} = \frac{1}{2}(M_q + M_{\dot{\alpha}} + \frac{Z_\alpha}{u_0}) \pm \frac{1}{2}\sqrt{(M_q + M_{\dot{\alpha}} + \frac{Z_\alpha}{u_0})^2 - 4(m_q \frac{Z_\alpha}{u_0} - M_\alpha)}$$

- **Natural Frequency:**

$$\omega_{sp} = M_q \frac{Z_\alpha}{u_0}$$

- **Damping Ratio:**

$$d_{sp} = -\frac{1}{2} \frac{M_1 + M_{\dot{\alpha}} + \frac{Z_\alpha}{u_0}}{\omega_{sp}}$$

Review

Approximations: Longitudinal Dynamics

Long Period Mode:

$$\lambda_{1,2} = \frac{X_u \pm \sqrt{X_u^2 + 4\frac{Z_u}{u_0}g}}{2}$$

- **Natural Frequency:**

$$\omega_{lp} = \sqrt{-\frac{Z_u g}{u_0}}$$

- **Damping Ratio:**

$$d_{lp} = -\frac{X_u}{2\omega_{lp}}$$

Review

Approximations:Lateral Dynamics

Spiral Mode:

$$\lambda_{spiral} = -\frac{L_r N_\beta - L_\beta N_r}{L_\beta}$$

Roll Mode:

$$\lambda_{roll} = L_p$$

Dutch Roll:

$$\omega_{DR} = \sqrt{\frac{1}{u_0} (Y_\beta N_r + N_\beta u_0 - N_\beta Y_r)}$$
$$d_{DR} = \frac{N_r + \frac{Y_\beta}{u_0}}{\omega_{DR}}$$