Survivability gateway

One page pulled from the Canon rooms named in the source column. Open the room before you quote a number in a design. This is not a copy of a Cisco document.

Check	What the room says	Source
Where do endpoints register in Active mode?	To the Webex cloud. [cite:1]	T2-R07-survivability-gateway.html
Where do they register in Survivability mode?	To the local Survivability Gateway. [cite:1]	T2-R07-survivability-gateway.html
How long must the cloud path be back?	At least 30 seconds. [cite:1]	T2-R07-survivability-gateway.html
What IOS starts the feature set?	IOS XE Dublin 17.12.3. Hunt group, call forward, and auto attendant start at 17.18.2. [cite:1]	T2-R07-survivability-gateway.html
What certificate types are refused?	Private or enterprise CAs, and wildcard certificates. [cite:1]	T2-R07-survivability-gateway.html
What hunt-group cap applies in this mode?	100 groups, 32 users each. Weighted routing is not supported. [cite:1]	T2-R07-survivability-gateway.html
What does Webex App support during the outage?	Internal extensions, PSTN in and out, outgoing emergency, hold and resume, transfer, inbound caller ID, and shared call appearance. [cite:2]	T2-R07-survivability-gateway.html

Back to the lab · Cheat Codes



A note from the student behind this lab

This is an **independent, free, learning-only student project**. It respects every company and vendor, and every trademark belongs to its owner. It is **not affiliated with or endorsed by** any of them.

If anyone has a concern, the content will be removed or corrected promptly: please write via **https://cyphermonkeylabs.com/#contact**. Nothing here is sold, and I am happy to volunteer for any organization.

© 2026 CypherMonkeyLabs 🐒

CypherMonkey Labs

MIT code. CC BY-NC-SA content.