

# **DSP/BIOSTM Link**

# **Platform Guide**

1.65.00.03

Published on 12<sup>th</sup>JUL 2010

**Copyright © 2010 Texas Instruments Incorporated.** 





#### **IMPORTANT NOTICE**

Texas Instruments Incorporated and its subsidiaries (TI) reserve the right to make corrections, modifications, enhancements, improvements, and other changes to its products and services at any time and to discontinue any product or service without notice. Customers should obtain the latest relevant information before placing orders and should verify that such information is current and complete. All products are sold subject to TI's terms and conditions of sale supplied at the time of order acknowledgment.

TI warrants performance of its hardware products to the specifications applicable at the time of sale in accordance with TI's standard warranty. Testing and other quality control techniques are used to the extent TI deems necessary to support this warranty. Except where mandated by government requirements, testing of all parameters of each product is not necessarily performed.

TI assumes no liability for applications assistance or customer product design. Customers are responsible for their products and applications using TI components. To minimize the risks associated with customer products and applications, customers should provide adequate design and operating safeguards.

TI does not warrant or represent that any license, either express or implied, is granted under any TI patent right, copyright, mask work right, or other TI intellectual property right relating to any combination, machine, or process in which TI products or services are used. Information published by TI regarding third-party products or services does not constitute a license from TI to use such products or services or a warranty or endorsement thereof. Use of such information may require a license from a third party under the patents or other intellectual property of the third party, or a license from TI under the patents or other intellectual property of TI.

Reproduction of information in TI data books or data sheets is permissible only if reproduction is without alteration and is accompanied by all associated warranties, conditions, limitations, and notices. Reproduction of this information with alteration is an unfair and deceptive business practice. TI is not responsible or liable for such altered documentation.

Resale of TI products or services with statements different from or beyond the parameters stated by TI for that product or service voids all express and any implied warranties for the associated TI product or service and is an unfair and deceptive business practice. TI is not responsible or liable for any such statements.

TI products are not authorized for use in safety-critical applications (such as life support) where a failure of the TI product would reasonably be expected to cause severe personal injury or death, unless officers of the parties have executed an agreement specifically governing such use. Buyers represent that they have all necessary expertise in the safety and regulatory ramifications of their applications, and acknowledge and agree that they are solely responsible for all legal, regulatory and safety-related requirements concerning their products and any use of TI products in such safety-critical applications, notwithstanding any applications-related information or support that may be provided by TI. Further, Buyers must fully indemnify TI and its representatives against any damages arising out of the use of TI products in such safety-critical applications.

TI products are neither designed nor intended for use in military/aerospace applications or environments unless the TI products are specifically designated by TI as military-grade or "enhanced plastic." Only products designated by TI as military-grade meet military specifications. Buyers acknowledge and agree that any such use of TI products which TI has not designated as military-grade is solely at the Buyer's risk, and that they are solely responsible for compliance with all legal and regulatory requirements in connection with such use.

TI products are neither designed nor intended for use in automotive applications or environments unless the specific TI products are designated by TI as compliant with ISO/TS 16949 requirements. Buyers acknowledge and agree that, if they use any non-designated products in automotive applications, TI will not be responsible for any failure to meet such requirements.

Following are URLs where you can obtain information on other Texas Instruments products and application solutions:

# Products Amplifiers amplifier.ti.com Data Converters dataconverter.ti.com DSP dsp.ti.com Interface interface.ti.com Logic logic.ti.com Power Mgmt power.ti.com

Microcontrollers microcontroller.ti.com

#### Applications

Audio www.ti.com/audio
Automotive www.ti.com/automotive
Broadband www.ti.com/broadband
Digital Control www.ti.com/digitalcontrol
Military www.ti.com/military

Optical Networking www.ti.com/opticalnetwork

Security www.ti.com/security
Security www.ti.com/security
Telephony www.ti.com/telephony
Video & Imaging www.ti.com/video
Wireless www.ti.com/wireless

#### Mailing Address:

Texas Instruments, Post Office Box 655303, Dallas, Texas 75265





# **Table of Contents**

Read This First	vi
1. Platform Guide for OMAPL138	1
1.1. Introduction	2
1.1.1. Purpose and Scope	. 2
1.1.2. Terms and Abbreviations	2
1.1.3. References	. 2
1.2. Configuring CCS	3
1.2.1. Configuring CCS for OMAPL138	3
1.3. Platform specific information	. 4
1.3.1. Boot mode support	
1.4. ADDITIONAL INFORMATION	. 5
1.4.1. Read write samples	5





# **List of Tables**

1.1.	Terms and	Abbreviations	 	 	2
1 2	References	<u>:</u>			7





# **Read This First**

## **About This Manual**

This document describes platform specific information need for OMAPL138 platforms.

## **How to Use This Manual**

This document includes the following chapters:

Please go through the Release Notes document available in the release package before starting the installation.

#### **Notation of information elements**

The document may contain these additional elements:



#### Warning

This is an example of warning message. It usually indicates a non-recoverable change.



#### Caution

This is an example of caution message.



#### **Important**

This is an example of important message.



#### **Note**

This is an example of additional note. This usually indicates additional information in the current context.



#### Tip

This is an example of a useful tip.



## If You Need Assistance

For any assistance, please send an mail to software support.

## **Trademarks**

 $\mathsf{DSP}/\mathsf{BIOS^{\scriptscriptstyle\mathsf{TM}}}$  is a trademark of Texas Instruments Incorporated.

All other trademarks are the property of the respective owner.



# **Platform Guide for OMAPL138**

# **Table of Contents**

1.1.	Introduction	2
	1.1.1. Purpose and Scope	2
	1.1.2. Terms and Abbreviations	2
	1.1.3. References	2
1.2.	Configuring CCS	3
	1.2.1. Configuring CCS for OMAPL138	3
1.3.	Platform specific information	4
	1.3.1. Boot mode support	4
1.4.	ADDITIONAL INFORMATION	5
	1.4.1. Read write samples	5



## 1.1. Introduction

## 1.1.1. Purpose and Scope

DSP/BIOS<sup>TM</sup> LINK is foundation software for the inter-processor communication across the GPP-DSP boundary. It provides a generic API that abstracts the characteristics of the physical link connecting GPP and DSP from the applications. It eliminates the need for customers to develop such link from scratch and allows them to focus more on application development.

This document provides the users necessary information to install DSP/BIOS $^{\text{\tiny TM}}$  LINK on the development host.

This document corresponds to the product release Version 1.65.00.03 dated JUL 12, 2010.

## 1.1.2. Terms and Abbreviations

CCS	Code Composer Studio
IPC	Inter Processor Communication
GPP	General Purpose e.g. ARM
DSP	Digital Signal Processor e.g. DM6437
DSPLink	A generic term used for DSP/BIOS <sup>TM</sup> Link. It appears in italics in all usages
CGTools	Code Gen Tools, e.g. Compiler, Linker, Archiver

**Table 1.1. Terms and Abbreviations** 

#### 1.1.3. References

1	User Guide
2	InstallGuide_Linux_OMAPL138.pdf
3	Porting Guide

Table 1.2. References



# 1.2. Configuring CCS

# 1.2.1. Configuring CCS for OMAPL138

To use CCS for debugging the DSP side application, you will need to configure CCS to use both ARM and DSP with the OMAPL138 EVM.

# 1.3. Platform specific information

## 1.3.1. Boot mode support

 $DSP/BIOS^{TM}$  LINK supports both ARM – boot mode as well as DSP – boot mode on OMAPL138.



## 1.4. ADDITIONAL INFORMATION

## 1.4.1. Read write samples

The addresses to be passed as parameters for readwrite samples are platform specific.

Read write sample can be used for addresses in DDR, GEM L1D RAM and L2 RAM on OMAPL138 platform.

