

## Fix Out of Sync Error 1









## Fix Out of Sync Error 2

(5) Find project top level, RIGHT CLICK / MENU / REFRESH

> (6) Close unwanted windows. Select ACQ400\_LAUNCHER, RIGHT CLICK | MENU | OpenWith ..! OPI Display (Workbench)







## Fix Out of Sync Error 2

