Setup SD Card

This sequence sets up an SD card as used by 4tronix

Setup OS and I2C

- 1. Download the latest Raspbian image (currently 16/2/2015)
- 2. Use Win32DiskImager to copy the image to a blank SD card
- 3. Boot into the card and within raspi-config set up the following:
 - a. Boot to desktop
 - b. Resize the card
 - c. Advanced options, setup I2C and load on boot
- 4. Save and reboot
- 5. From LXTerminal:
 - a. sudo apt-get update
 - b. sudo apt-get install python-smbus
 - c. sudo nano /etc/modules and add "i2c-dev" as the last line

Install VNC

- wget http://goo.gl/MbfUEp -O isx11.sh
- sudo bash isx11.sh
- Depending on the VNC client you use, you may want to remove the -display and -file transfer commands from the startup file
 - cd .config/autostart
 - sudo nano x11vnc.desktop
 - remove everything after "Exec=x11vnc -forever -usepw" on that line
 - save and exit
- sudo reboot

Install and Test Pi2Go Software

- wget http://4tronix.co.uk/pi2go.sh -O pi2go.sh
- bash pi2go.sh
- cd pi2go
- sudo python motorTest.py