
# DC-ROMA PAD II Troubleshooting Guide

Document Properties	
Document Version	V1.0
Latest Release Date	April 26, 2025
Applicable Product model	DC-ROMA PAD II
Operating System Version	Ubuntu 24.04 or Fedora 41
Document Target Audience	DC-ROMA PAD II Users
Hardware Specifications	The TF card model mentioned in this document is SanDisk HIGH ENDURANCE (32GB). For other compatible TF card models, refer to: Compatibility List

## **Catalog**

Step 1: Check if the Power Indicator Light is On
Step 2: Insert a Preloaded System TF Card and Attempt to Power On Again
Step 3: Connect a PD-Compatible Adapter and Check if the Charging Indicator Light
s On



### Step 1: Check if the Power Indicator Light is On

# 1.1 After Pressing the Power Button, the Power Indicator Light Turns On



#### 1.1.1 Startup Logo is Visible

```
| Note | Property | Company | Compan
```

◆ If the startup logo appears, re-burn the TF card and attempt to power on again → Proceed to Step 2

DeepComputing.io

#### 1.1.2 Startup Logo is Not Visible



♦ If the boot screen is not visible, the Uboot may be corrupted. Reflash the system using the upgrade image. Guide.

# 1.2 After Pressing the Power Button, No Response (Power Indicator Light Off)



■ Connect a PD-compatible adapter and check if the charging indicator light turns on → Proceed to Step 3

# Step 2: Insert a Preloaded System TF Card and Attempt to Power On Again



#### 2.1 System Still Fails to Boot After Reflashing

2.1.1 If the system still fails to boot after reflashing, the TF card may be corrupted. Re-burn the TF card and attempt to power on again.


Scenario 1: Successful Boot
Scenario 2: If the system still fails to boot, there may be a hardware issue with the TF card slot. This is a device malfunction. Contact DeepComputing Support at support@deepcomputing.io.

#### 2.2 Successful Boot into System

If the system boots normally, the eMMC firmware may be faulty. Reflash the firmware to the eMMC.

# Step 3: Connect a PD-Compatible Adapter and Check if the Charging Indicator Light is On

# 3.1 Charging Indicator Light Turns On: Attempt to Power On




#### **3.1.1** No Response After Pressing the Power Button

◆ If there is no response after pressing the power button, there may be an issue with the power button circuit. This is a device malfunction. Contact DeepComputing Support at support@deepcomputing.io.


#### 3.1.2 Successful Power-On

♦ If the device powers on normally, the device is functioning properly.


# 3.2 Charging Indicator Light Does Not Turn On: Replace with a PD-Compatible Adapter



#### 3.2.1 Charging Indicator Light Turns On → Refer to 3.1



#### 3.2.2 Charging Indicator Light Still Off



◆ If the charging indicator light remains off, there may be a power supply or charging circuit issue. This is a device malfunction. Contact DeepComputing Support at support@deepcomputing.io.