

LockDown™ Universal





Installation Instructions
















Locking Solution Options





Secure Cable

- Anchor the cable loop end of your security lock around a non-movable object.
- 2. Press and hold the release button, then insert the locking hook into the lock slot of your tablets case, holder or laptop.





- 1. Turn the dials to the default combination 0-0-0-0.
- Turn the reset button 90 degrees clockwise with a small flathead screwdriver, coin or similar
- 3. Turn the dials to set the desired combination.
- 4. Turn the reset button 90 degrees counterclockwise back to its original position. Your lock can now be opened using the combination you just set

