SDK - HTHardDll.dll Manual

VC++6.0 IDE

Note:

HTHardDll.dll was compiled under VC++6.0.

WORD: unsigned short

BOOL: bool

ULONG: unsigned long

The following ifdef block is the standard way of creating macros which make exporting from a DLL simpler. All files within this DLL are compiled with the DLL_API symbol defined on the command line. this symbol should not be defined on any project that uses this DLL. This way any other project whose source files include this file see DLL_API functions as being imported from a DLL, wheras this DLL sees symbols defined with this macro as being exported.

```
#ifndef    DLL_API
#define    DLL_API    extern "C" __declspec(dllimport)
#endif
```

Define __stdcall:

```
#define WIN_API __stdcall
```

Defines the struct for the application.

_HT_CONTROL_DATA contains some controls

```
#ifndef struct_HT_CONTROL_DATA
#define struct_HT_CONTROL_DATA  //avoid Redenification.
  typedef struct _HT_CONTROL_DATA
  {
        WORD nCHSet;//Channel Enable/Disable
                    //The 0 bit: 0 is enable, 1 is disable.
                    // The 1 bit: 0 is enable, 1 is disable.
                    // The 2 bit: 0 is enable, 1 is disable.
                    // The 3 bit: 0 is enable, 1 is disable.
        WORD nTimeDIV;          //The index of time Base
        WORD nTriggerSource;    // The index of the trigger source
        WORD nHTriggerPos;      //The Horizontal Trigger Pos (Value: 0 ~ 100)
        WORD nVTriggerPos;      //The Vertical Trigger Pos (Value: 0 ~ 255)
        WORD nTriggerSlope;     //The Edge trigger Slope (Rise slope is 0,Fall slope is 1)
        ULONG nBufferLen;       //The buffer Length
```

```
    ULONG nReadDataLen;      //The Data Length of have be read.
    WORD nALT;               // Is alternate trigger or not

}CONTROLDATA,*PCONTROLDATA;
#endif
```

Function Declaration：

This modul uses for data processing,independent of hardware

SourceData : date to be process

BufferData ： processed data。

nInsertMode ： Insertion Mode. 2 (default) sine, 1 line, 0 Step

pState：soft trigger position of 18 channels. after data insertion, find out the best trigger position by soft trigger.

TriggerPoint：one value of pState array.