
TT210303 - OPENview - Graphic Option Expire


1. The OPEN EMS controller has built-in Web server and you can access the controller via HTML 5 browsers, OPENview Control Panel, or OPENview App in Android device



2. This function is free of charge, but if you want to view the graphics in the controller (like above), you need to purchase the "DS-OVx" option for each controller, for example



3. If you didn't purchase the option, you can still view the controller in text mode, i.e. all the HTML pages in the controller, so you still have access to all points and parameters in the controller



4. A few controller types have the graphical user interface option for free, but many do not. When you access the controller via HTML 5 browser, if you see the below message on the top-right hand corner, this means your controller don't have this option

Demo time remaining: 175 days

- 5. All controllers have this demo option enabled for about 6 months for free. This allows you to setup the controller in commissioning phase using the graphical user interface (without paying)
- 6. After the demo time goes down to 0 (i.e. expired), you will not be able to view the graphic pages anymore. To verify if you've purchased the option or not in the controller, please refer to "TT190401-OPEN-Controller Options" for details, together with the steps to upgrade the controller with the option

Change Controller Options		
Serial Number: Device Code:	OPEAA11781 01-03-3018CF002E05-1ED5E-0A3D6-4698Z	
Last Confirmation:		
Enter new Code:		
Submit	Bac	<u>ck</u>

7. Please note that you don't need this option to view the graphic pages in the controller using OPENweb Control Panel. Once you've configured the controller in OPENweb, you can view all the graphics without any limits