

TT230401 - OFXL - Controller Backup and Restore


1. In OPEN FXL 4, we can backup the controller including the firmware, controller program and parameters. To do it, right click on the controller, select "Backup and restore", "Backup".



2. You should see the *if* the controller is online and the firmware version support this function. Tick the controller in the checkbox ✓ and click "Download" to backup the controller.



The backup will start. It may take 10 minutes or more, so please wait until it's finished.



4. The first time it will backup all data including firmware, controller program and parameters.


```
Output - FUP log × Info center

2022-11-04 15:05:22.835 [INFO] ISP01: Backup is being created
2022-11-04 15:09:50.484 [INFO] ISP01: Connection is being established.
2022-11-04 15:10:01.073 [INFO] ISP01: Firmware is being downloaded
2022-11-04 15:14:08.769 [INFO] ISP01: Project is being downloaded
2022-11-04 15:14:16.402 [INFO] ISP01: Data is being downloaded
2022-11-04 15:14:17.739 [INFO] ISP01: Backup downloaded
2022-11-04 15:14:17.739 [INFO] ISP01: Connection is being tested
2022-11-04 15:14:18.624 [INFO] ISP01: Connection test successful
```


5. Later if you do the backup again, it will check whether the firmware and controller are changed. If not, it will only backup the parameters.

| □ Details □ Testing - | Backup × | | |
|--------------------------|------------|---|--|
| Download $ \mathbb{C} $ | | | |
| Desired assets Teatler | | | |
| Project name: Testing | | | |
| ✓ ISP01 | CREATE NEW | Firmware Controller program Parameter 🕢 | |


6. To restore the controller, right click on the controller, select "Backup and restore", "Restore".




7. Select the "Date/Time" of the backup that you want to restore to the controller. The program will automatically detect if the firmware and controller program have been changed, and only restore the necessary. In this case, only the parameters are restored.



8. Click the "Upload" button to start restoring the backup to the controller.



9. The restart will start. Wait until it's finished.



10. It's done.

```
Output - FUP log × Info center

2022-11-04 15:38:15.507 [INFO] ISP01: Connection test successful
2022-11-04 15:41:43.745 [INFO] ISP01: Restore is being initialized
2022-11-04 15:41:43.818 [INFO] ISP01: Backup is being validated.
2022-11-04 15:41:53.853 [INFO] ISP01: Data is being loaded onto OPEN.
2022-11-04 15:41:55.582 [INFO] ISP01: Backup loaded onto OPEN. Restore started on the controlled accordance of the controll
```

11. It's recommended to backup your controllers regularly, especially before you upgrade the controller firmware.