

## TT221004 - OFXL - License, Login and Logout


- 1. OPEN FXL 4 use software license, so you don't need to use the dongle anymore. To switch your exiting dongle license to software license, please refer to the technical tip TT220801.
- 2. You'll be asked to login when you start OPEN FXL 4. To login, you need Internet access and also in your firewall settings, you need to allow outgoing access to TCP ports 1947 and 443.




3. You can still use OPEN FXL 4 without login by clicking CANCEL. You can still do most of things, e.g. editing FUP page, but you'll not be allowed to load the controller without login (and a few other functions).




4. Type your user name (or e-mail address) and password and click LOG-IN to access all functions.




5. You should now see a green icon on the bottom right corner showing OPEN FXL is activated, and you can do everything now.



6. On the bottom left corner, you can see a message saying "Offline use authorized until". This means you can continue to use OPEN FXL 4 with all functions when offline (i.e. without Internet access) for up to 1 month (unless you logout OPEN FXL 4 manually).



7. When you close OPEN FXL 4, you will be asked to whether you want to close it or not, click OK to close it.



8. You'll then be asked if you want to stay logged in after you close OPEN FXL 4. Click "Yes" if this is your normal working PC. **Note:** If you click "No", then you will need to login again (must have Internet access) next time you start OPEN FXL 4.




- 9. This feature allows you to continue to work on your projects on-site without Internet access for up to 1 month. **Note:** Each time you start OPEN FXL 4 with Internet access (and the required ports open), the date will be updated and extended for another month.
- 10. To make sure you won't click the wrong button when closing, you can tick the "Don't ask again" option, and click "Yes" to stay logged in every time you close OPEN FXL 4.




- 11. **Note:** the OPEN FXL 4 software license required Internet access for login. After login, you're allowed to use it without Internet access for up to 1 month (make sure you don't logout).
- 12. Note: If not using OPEN FXL 4 within 1 month, you need to login again with Internet access


- 13. It is possible to use OPEN FXL 4 on multiple PC. To do it, first logout from your existing PC.
- 14. To logout OPEN FXL 4, click "User" and then "Logout". **Important note:** make sure you've Internet access (and TCP ports 1947 and 443 are open) before doing it. Otherwise, you may not be able to login again on another PC.



15. If you need to access the license server to check your license details, click "User" and then "To user management", and you'll then be redirect to the license server at <a href="https://licserver.deos-ag.com/">https://licserver.deos-ag.com/</a>.



16. If you need to reset the "Don't ask again" option, click "Tools" and then "Options".



17. Go to "Preference" tab, you can find the (Reset "Don't ask again") button at the bottom under "Miscellaneous".

