

## TT180809 - OPENview - BACnet MSTP Setup


- Connect the bus of the BACnet MS/TP device to the COM3 "A+" and "B-" terminal of the controller
- 2. Start Chrome. Login to your controller. Click "Service Controller", "Protocol", "BACnet MS/TP". Select "COM3" and click "Save Changes" (in some cases, you may need to change to baud rate according to your BACnet device)




3. Click "System", "BACnet", and select "BACnet MS/TP" TAB




4. Tick the "MS/TP Network Active" and "BACnet Device ON". Change the "Max Master" to 127. If you have more than one MS/TP bus, then you need to change to "Network Number" to different value in each controller, e.g. 6662, 6663, etc.



5. Scroll down to the bottom. Tick the "Time Synchronization" if you want to synchronize the clock with the BACnet MS/TP device. Click "Save Changes"



6. Click "Restart BACnet Process". You should see the below pop-up window. If not, you may see this icon in your browser, and please set "Always allow pop-ups from [site]", and try again



7. Now the COM3 LED on the controller should start flashing. Wait for a while, and click the "Reload" button and you will see the MS/TP bus details below

