First XDJ-XZ mapping for Traktor Pro 3 with JogScreens.


The jog screens require the BOME midi translator. A free trial is available in https://www.bome.com

IMPORTANT: do NOT set XDJ-XZ in the controller manager. Put the BOME device there instead!

These slides show the basic configuration for the XDJ-XZ. For more details, please see the DDJ-1000 specific guide.

For a feature demo, see the videos on: https://www.youtube.com/user/djestrela2/playlists


Proper BOME config:




Proper BOME log:

```
795: MIDIManager stopped.
796: AIDIManager started.
797: Opened MIDI OUTPUT 'Bome MIDI Translator 1 Virtual Out'
798: Opened MIDI OUTPUT 'XDJ-XZ (2)'
799: Opened MIDI OUTPUT 'XDJ-XZ (1)'
800: Opened MIDI INPUT 'Bome MIDI Translator 1 Virtual In'
801: Opened MIDI INPUT 'XDJ-XZ (2)'
802: Spened MIDI INPUT 'XDJ-XZ (1)'

| Incoming | Rules | Outgoing | MIDI IN | MIDI OUT | Timestamped
```







DO NOT put XDJ-XZ here!!!