
DDJ-1000: Pad modes



Most modes have sub-pages:

- Press "mode" to cycle the top 2 pages
- Press "<" to cycle all pages one by one</p>
- Press ">" to select a specific page
- Press "shift" to select a specific page

DDJ-1000: Jog Screens






Preview base BPM, Tempo range and loop sizes





Set Tempo range






Screens Reset






Set elapsed/remain

DDJ-1000: Jog Screens and LEDs








DDJ-1000: General overview - Mixer




DDJ-1000: MixerFX and UserFX









DDJ-1000: MixerFX and UserFX







DDJ-1000: Loop Section







DDJ-1000: BeatJump Section







DDJ-1000: Sync Section

TRAKTOR MODE

SERATO MODE



Toggle ON/OFF

Phase Sync





Set master deck (always)





Sync Off (always)







Toggle Traktor/Serato sync mode

DDJ-1000: Browser












DDJ-1000: Transport








DDJ-1000: Beatgrid






DDJ-1000: Mapping Settings




DDJ-1000: Pad modes



Most modes have sub-pages:

- Press "mode" to cycle the top 2 pages
- Press "<" to cycle all pages one by one
- Press ">" to select a specific page
- Press "shift" to select a specific page

DDJ-1000 mode #1: HotCues



- Use shift to delete hot cues
- Hotcues move temporary cue as well


DDJ-1000 mode #2: PadFX and Rolls

MAIN PAGES: **EXTRA PAGES:** Rolls PadFX 2 Delay / **Roll 1/8** Roll 1/4 **Roll 1/2** Roll 1/1 Flanger Flux Delay #1 Delay #2 BeatSlicer **Roll 1/8** Roll 1/4 **Roll 1/2** Roll 1/1 Lofi / Lofi / Release FX BeatSlicer (NQ) (NQ) (NQ) (NQ) Slicer #2 Slicer #1 (toggle) PadFX 1 PadFX 3 Bass-O-Bass-O-Gater #1 Peak Filter Filter Pulse LaserSlicer Gater #2 Gater #3 Matic #1 Matic #2 Beat Beat Release FX Bouncer / Release FX Zzzurp Bouncer EventH (toggle) Masher #1 Masher #2 EventH (toggle)

- Use mode button to cycle top two pages
- Use "<" arrow to cycle all pages
- Use ">" or "shift" to select a specific page

DDJ-1000 mode #3: MixerFX and MacroFX

MAIN PAGES: Macro FX1 MacroFX: MacroFX: MacroFX: MacroFX: WormHole **PolarWind** FlightTest LaserSlicer BeatFX: BeatFX: BeatFX: Toggle Delay T3 On/OFF Flanger Reverb MacroFX2 Bass **Event** Dark Zzzuurp Horizon Matter Matic Strrretch Strrretch Granu **Toggle** On/OFF Phase (Slow) (Fast)



- Use mode button to cycle top two pages
- Use "<" arrow to cycle all pages
- Use ">" or "shift" to select a specific page


DDJ-1000 mode #4: JogFX

JOG FX EventHorizon Beatmasher Beatmasher Gater Digital filter Filter (none) Beatmasher Gater Reverb Gater Reverb Flanger Beatmasher FormatFilter (None) Peak filter Peak filter Flightest Gater Gater





- Enter jogFX mode on mode4 (jog will blink)
- Touch jog to apply FX
- Turn jog to change FX
- Release jog to stop FX
- Sampler volume to Dry/Wet
- Call "hotcues" to cancel jogFX (=scratch mode)

DDJ-1000 mode #5: Tone Play




Use shift to choose between 3x modes:






DDJ-1000 mode #6: BeatJumps and Loops




- Use "<" arrow to select beatjump mode
- Use ">" arrow to select loop mode


DDJ-1000 mode #7: Slicer



Use shift to choose between 3x modes:



DDJ-1000 mode #8: Sampler



Use shift to mute / Toogle 1-shot

