
DDJ-1000: Jog Screens






Show base BPM, Tempo range and loop sizes






Tempo range





Screens Reset






Time elapsed/remain

DDJ-1000: Jog Screens and LEDs RESET SCREENS Show Loop size / Vinyl On/Off Show BeatJump Size 2/4 On-Air Deck / End of track warning JogFX enabled ±0 c 137.8 0.0% Show Tempo Range, Base BPM, Loop sizes CUE / LOOP DE Tempo Range Toggle Elapsed & Remain Toggle Time Elapsed / Remain Tempo adjust CUE flashes when a new cue can be set PLAY/PAUSE PLAY flashes when in pause mode




DDJ-1000: General overview - Mixer




DDJ-1000: Pad modes


Each mode has several sub-pages. Per mode:


- Press "mode" to cycle the top 2 pages
- Press "<" to cycle all pages one by one
- Press ">" to select a specific page



DDJ-1000: MixerFX and UserFX







DDJ-1000: Loop Section







DDJ-1000: BeatJump Section







DDJ-1000: Sync Section

TRAKTOR MODE

SERATO MODE



Toggle ON/OFF

Phase Sync





Set master deck (always)





Sync Off (always)









Toggle Traktor/Serato sync mode


DDJ-1000: JogFX







DDJ-1000: MixerFX and MacroFX












DDJ-1000: PadFX





DDJ-1000: Keyboard







Use shift to choose 3x modes:







DDJ-1000: BeatJumps and Loops







DDJ-1000: Browser






DDJ-1000: Transport







DDJ-1000: Beatgrid





DDJ-1000: Mapping Settings

