
Push 2 Pedal Remap



Push 2 Pedal Remap allows you to modify the CC messages sent by Push 2's pedal inputs. This lets you remap them freely while in Live or User Mode.

Configuration

Load Push 2 Pedal Remap into an empty MIDI track. This track should be used exclusively for the device. Set the track's Input to "Ableton Push 2 (Port 2)" so it receives MIDI messages through the User Port, and the Output to "Push2 Output (Ableton Push 2)" so the device can send MIDI messages to Push's Live Port.



Usage

Each Pedal has an *Assign* button, a numeric CC value slider, and a *Default* button. Select the CC value you want each pedal to send, then click the *Assign* button. This will reconfigure the corresponding pedal to send that CC value out through the User port, allowing them to be MIDI mapped as a regular controller.

The *Default* buttons restore each pedal to their factory configuration. Use these when you want to return to the default Sustain and Session Record functionality.

The *Pedal to Session Record* button enables/disables the use of the remapped Pedal 2 as a Session Record control. This is a simpler alternative to Push's default Session Record control, which removes the short delay before it is activated, but loses the double tap functionality.

Note: MIDI mapping Pedal 2 bypasses the *Pedal to Session Record* functionality.