
# **ENCODER BOARD POPULATION LEGEND**



#### **T41 VOLUME ENCODER (ENCODER #1)**

POPULATE C1-C6 WITH 0.01 UF CAPACITORS (RED LINES)

POPULATE R4, R6 WITH OR/ JUMPERS (ORANGE LINES)

POPULTATE R7, R8 (NOT R9, R10) WITH OR/JUMPERS FOR CW OPERATION (YELLOW LINES)

POPULATE R9, R10 (NOT R7, R8) WITH OR/JUMPERS FOR CCW OPERATION (GRAY LINES)

**V11** LEAVE R1, R2 EMPTY (SWITCH NOT ACTIVE)

V12 POPULATE R1 WITH OR/ JUMPERS (SWITCH ACTIVE)

### **T41 FINE TUNE ENCODER (ENCODER #2)**

POPULATE C1-C6 WITH 0.01 UF CAPACITORS (RED LINES)

POPULATE R3, R5 WITH OR/JUMPERS (PURPLE LINES)

POPULTATE R7, R8 (NOT R9, R10) WITH OR/JUMPERS FOR CW OPERATION (YELLOW LINES)

POPULATE R9, R10 (NOT R7, R8) WITH OR/JUMPERS FOR CCW OPERATION (GRAY LINES)

**V11** LEAVE R1, R2 EMPTY (SWITCH NOT ACTIVE)

V12 POPULATE R2 WITH OR/ JUMPERS (SWITCH ACTIVE)

# **T41 TUNE ENCODER (ENCODER #3)**

POPULATE C1-C6 WITH 0.01 UF CAPACITORS (RED LINES)

POPULATE R3, R5 WITH OR/ JUMPERS (PURPLE LINES)

POPULTATE R7, R8 (NOT R9, R10) WITH OR/JUMPERS FOR CW OPERATION (YELLOW LINES)

POPULATE R9, R10 (NOT R7, R8) WITH OR/JUMPERS FOR CCW OPERATION (GRAY LINES)

**V11** LEAVE R1, R2 EMPTY (SWITCH NOT ACTIVE, MATRIX CONNECTOR USED)

V11 ADD THREE IDC PINS FOR THE SWITCH MATRIX CONNECTION (PINK LINES)

V12 POPULATE R1 WITH OR/ JUMPERS (SWITCH ACTIVE)

# **T41 FILTER ENCODER (ENCODER #4)**

POPULATE C1-C6 WITH 0.01 UF CAPACITORS (RED LINES)

POPULATE R4, R6 WITH OR/ JUMPERS (ORANGE LINES)

POPULTATE R7, R8 (NOT R9, R10) WITH OR/JUMPERS FOR CW OPERATION (YELLOW LINES)

POPULATE R9, R10 (NOT R7, R8) WITH OR/JUMPERS FOR CCW OPERATION (GRAY LINES)

V11 LEAVE R1, R2 EMPTY (SWITCH NOT ACTIVE)

V12 POPULATE R2 WITH OR/ JUMPERS (SWITCH ACTIVE)

NOTE: DAISY CHAIN ENCODERS 1 & 2 ON SAME CABLE, 3 & 4 ON SAME CABLE.