




此核心板支持STM8L051F3/STM8L101F3两种芯片，可以自行更换芯片。

板子正面有低压差LDO芯片ME6211，板子背面1117请忽略，备用

TEST为电流测试口，可以测CPU功耗，仪器请串联接入，拔掉跳线

Y1请根据需要自行焊接，晶振附送，芯片有内置晶振，101只支持片内晶振

Y2根据量产批次，U2是340C时，不用焊接，勿以为漏焊

芯片051时，请短接1-3 2-4

芯片101时，请短接3-5 4-6

电流测试口，拔掉跳线，仪器串联接入即可测CPU功耗

Title		
Size	Number	Revision
B		
Date:	2019-06-09	Sheet of
File:	E:\dianlu\stm8l051-101 Sch	Drawn By:

This core board supports two types of chips, STM8L051F3 and STM8L101F3, and you can replace the chips by yourself. There is a low dropout LD0 chip ME6211 on the front side of the board. Please ignore the 1117 on the back side of the board. The spare TEST is the current test port, through which you can measure the power consumption of the CPU. The instrument should be connected in series. Pull out the jumper Y1 and weld it according to your needs. The crystal oscillator is provided. The chip has a built - in crystal oscillator. The 101 only supports the internal - chip crystal oscillator. Y2 depends on the mass - production batch. When U2 is 340C, there is no need to weld it. Don't mistake it as a missed welding.

When using the 051 chip, short - circuit 1 - 3 and 2 - 4.
When using the 101 chip, short - circuit 3 - 5 and 4 - 6.

For the current test port, pull out the jumper, and connect the instrument in series to measure the CPU power consumption.