





RMII TXD1	GPIO35
RMII_TXD0	GPIO34
MDC	GPIO31
RMII_RXD1	GPIO30
RMII_RXD0	GPIO29
RMII_RXDV	GPIO28
MDIO	GPIO52
PHY_RSTN	GPIO51
RMII_CLK	GPIO50
RMII_TXEN	GPIO49
ES7210_SDOUT	GPIO48
CODEC 12SO DSDIN	GP109
CODEC 12SO MCLK	GP I 0 1 3
CODEC 12SO SCLK	GP I 0 1 2
CODEC 12SO LRCK	GP I 0 1 0
ES 12C SDA ES 12C SCL	RTC DAT/SDA1 RTC CLK/SCL1
ES 12C SDA ES 12C SCL	GP107 GP108
22P/25V	C4C 22P/25V
	GND R44 ESP_3V3












## ADC&AEC








DSI屏幕



CSI摄像头







## Capacitive touch

