Lesson-11 Instructions

Note: If the device is not connecting to the mosquitto broker, it is possible that the versions that you are running is different from what I have used in this course. You can check if mosquitto is listening on port 1883 from local host as well as external host by running the following command on your cloud server.

netstat -a |grep 1883

###You should be seeing a line in the output as follows:

```
tcp 000.0.0:18830.0.0.0:*
```

##If not, add the following line in /etc/mosquitto/conf.d/default.conf
listener 1883 0.0.0.0
###Then restart mosquitto

sudo systemctl restart mosquitto

###Then test if the device is connecting to mosquitto broker without any problem.