Design Details of Boho Wooden Swing Chair

Brand Name	WoodWorks
Finish	Walnut finish
Material	Sheesham wood
Dimensions(Inch)	54 L x 26 W x 20 H
Dimensions (Cm)	137.2 L x 66 W x 50.8 H
Backrest	Yes
Product Weight	42 Kg
Delivery Condition	Expert-Assembly
Manufacturer Country	Sri Lanka
Care & Instructions	 Dust the furniture regularly. Wipe the wooden surface with a clean microfiber cloth damped in a wood-friendly cleanser. Immediately wipe the moisture with a dry, soft, and lint-free cloth. In case of a spill, blot the stain with a clean, dry cloth in a gentle manner. Please make sure you do not use coarse material or rub the spot briskly. Use mats and coasters before keeping any hot or cold items on the wooden surface. Ensure that the furniture does not have any exposure to moisture and water. Protect the material from direct sunlight and heat to maintain its original quality. Keep sharp objects away from your furniture to avoid cuts and scratches. Avoid chemical and alcohol contact with the furniture as it might harm

the natural finish and durability of the product. • Please note: Do not drag the furniture to relocate it, as this might
weaken the joints. Instead, lift the wooden furniture if you want to move it.