Naam	Command	# Mode	Response
RPM	b'010C'	1	0.0 revolutions_per_minute
CVN	b'0906'	9	
BAROMETRIC_PRESSURE	b'0133'	1	100 kilopascal
STATUS_DRIVE_CYCLE	b'0141'	1	<obd.OBDResponse.Status object at 0x1046fdf10>
GET_CURRENT_DTC	b'07'	7	
DTC_AMBIANT_AIR_TEMP	b'0246'	2	
DTC_DISTANCE_W_MIL	b'0221'	2	
DTC_RPM	b'020C'	2	
PIDS_C	b'0140'	1	11000100000000000000000000000001
CALIBRATION_ID	b'0904'	9	
DTC_PIDS_B	b'0220'	2	
PIDS_9A	b'0900'	9	
ELM_VERSION	b'ATI'		
RUN_TIME	b'011F'	1	
DTC_STATUS	b'0201'	2	
DTC_SPEED	b'020D'	2	
AMBIANT_AIR_TEMP	b'0146'	1	13 degree_Celsius
DTC_ENGINE_LOAD	b'0204'	2	
ELM_VOLTAGE	b'ATRV'		
DTC_THROTTLE_POS	b'0211'	2	
DTC_CONTROL_MODULE_VO	b'0242'	2	
CLEAR_DTC	b'04'	4	
COOLANT_TEMP	b'0105'	1	18 degree_Celsius
DTC_BAROMETRIC_PRESSUI	b'0233'	2	
DTC_STATUS_DRIVE_CYCLE	b'0241'	2	
SPEED	b'010D'	1	0.0 kilometer_per_hour
PIDS_B	b'0120'	1	10000000000000010010000000000001
CONTROL_MODULE_VOLTAG	b'0142'	1	
DTC_RUN_TIME	b'021F'	2	
MIDS_A	b'0600'	6	
DISTANCE_W_MIL	b'0121'	1	0.0 kilometer
ENGINE_LOAD	b'0104'	1	0.0 percent
STATUS	b'0101'	1	<obd.OBDResponse.Status object at 0x104636d50
DTC_COOLANT_TEMP	b'0205'	2	
WARMUPS_SINCE_DTC_CLE/	b'0130'	1	59.0 count
THROTTLE_POS	b'0111'	1	89.01960784313725 percent
PIDS_A	b'0100'	1	10011000000110001000000000000011
DTC_PIDS_C	b'0240'	2	
GET_DTC	b'03'	3	
DTC_WARMUPS_SINCE_DTC.	b'0230'	2	