

and related rights are licensed under the Solderpad Hardware License, 531 (Me "Licence"); you may not use this file except in compliance license. You may not use this file except in compliance dependancy licenses All—0.51. The property of the Licence at the compliance provided paper and paper an Copyright and related rights are licensed under the Solderpad Hardware Liversion OSI (the "Liceners") you may not use this file except in compliance with the Licence. You may obtain a copy of the Licence at the compliance they /soldepad.org/licenses/SH-051.

Unless required by applicable law or agreed to in writing, software, hardware and materials distributed under this Licence is distributed on an "MS IS" BASIS, MITHOUT MARRANIES OR CONDITIONS of MY KIND, either express or implied. See the Licence for the specific language governing permissions and limitations under the Licence.

REU: 2

Sheet: 1/1

Date: 15/04/2016 17:42

Document Number:

TITLE: rev10

Author(s) / Copyright (s): Bo Herrmannsen 2013--2014, Damon Hart-Davis 2013--2014, Mike Stirling 2013