

Esc ~ `	1 L1	2 L2	3 L3	4 L4	5
Tab	Q	W	E	R	T
Shift	A	S	D	F	G
Ctrl	Z L1 Light	X	C	V	B
		Space L2	Enter L4	L1 Tgl	
			Alt	Back Space	





BASE (L0)					
6	7	8	9	0	-
Y	U	I	O	P	\
H	J	K	L	+ :	'
N	M	,	.	/ L1	Shift
	Delete	Enter L2			
	Back Space				

SYMBOLS + NUMPAD (L1)					
~	!	@	#	\$	%
Tab	-	7	8	9	*
Exit	+	4	5	6	/
Ctrl	0	1	2	3	=
		Space Exit	Enter Exit	L1 Tgl	
			Alt	Back Exit	

^	&	*	(	)	_
[	[	]	{	}	PSCR
+	Left	Up	Down	Right	=
Hue +	Hue -	Sat +	Sat -	Brt +	Brt -
	L2 Tgl	Enter Exit			
	Back Exit				

MEDIA (L2)					
F12	F1	F2	F3	F4	F5
PSCR	Exit	Exit	Exit	Exit	
Shift	Left	Up	Down	Right	RGB Auto
Exit	Home L3	Page Up	Page Down	End	
		Space Exit	Enter Exit	L1 Tgl	
			Delete	Back Exit	

F6	F7	F8	F9	F10	F11
FIRE	[	]	{	}	rgb -
Shift	Left	Down	Up	Right	rgb +
	Home	Page Up	Page Down	End	
	L2 Tgl	Enter Exit			
	Back Exit				



COMBOS & SPECIAL ACTIONS

- A + S

S + D

D + F

F + G

J + K

Z (Tap)

Z (Hold)

Z (Dbl-Tap)
- : Left Arrow

: Up Arrow

: Down Arrow

: Right Arrow

: Delete

: Z

: Layer 1

: Flashlight (White)