Ministerul Educatiei al Republicii Moldova Universitatea Tehnica a Moldovei Filiera Anglofona



Laboratory Nr.1

Embeded Systems

Performed By:

Verified By:

Andrei Bragarenco

Topic: Introduction to MCU. Serial Interfacing using USART.

Task: Write a basic program that will display every second the message "Hello World!" in the virtual terminal. The simulation will be done in the on the circuit build in Proteus.


Theory:

A microcontroller is a self-contained system with peripherals, memory and a processor that can be used as an embedded system. Most programmable microcontrollers that are used today are embedded in other consumer products or machinery including phones, peripherals, automobiles and household appliances for computer systems. Due to that, another name for a microcontroller is "embedded controller." Some embedded systems are more sophisticated, while others have minimal requirements for memory and programming length and a low software complexity. Input and output devices include solenoids, LCD displays, relays, switches and sensors for data like humidity, temperature or light level, amongst others.

Applications for Microcontrollers:


Programmable microcontrollers are designed to be used for embedded applications, unlike microprocessors that can be found in PCs. Microcontrollers are used in automatically controlled devices including power tools, toys, implantable medical devices, office machines, engine control systems, appliances, remote controls and other types of embedded systems.

MCU Architecture:



Atmega32 AVR microcontroller:

ATmega32 is an 8-bit high performance microcontroller of Atmel's Mega AVR family. Atmega32 is based on enhanced RISC (Reduced Instruction Set Computing) architecture with 131 powerful instructions. Most of the instructions execute in one machine cycle. Atmega32 can work on a maximum frequency of 16MHz.



What is UART?

The Universal Asynchronous Receiver/Transmitter (UART) controller is the key component of the serial communications subsystem of a computer. The UART takes bytes of data and transmits the individual bits in a sequential fashion. At the destination, a second UART re-assembles the bits into complete bytes. Serial transmission is commonly used with modems and for non-networked communication between computers, terminals and other devices.

There are two primary forms of serial transmission: Synchronous and Asynchronous. Depending on the modes that are supported by the hardware, the name of the communication sub-system will usually include a A if it supports Asynchronous communications, and a S if it supports Synchronous communications. Both forms are described below.

Some common acronyms are:

UART Universal Asynchronous Receiver/Transmitter


Asynchronous transmission allows data to be transmitted without the sender having to send a clock signal to the receiver. Instead, the sender and receiver must agree on timing parameters in advance and special bits are added to each word which are used to synchronize the sending and receiving units.

USART Universal Synchronous-Asynchronous Receiver/Transmitter

Synchronous serial transmission requires that the sender and receiver share a clock with one another, or that the sender provide a strobe or other timing signal so that the receiver knows when to "read" the next bit of the data. In most forms of serial Synchronous communication, if there is no data available at a given instant to transmit, a fill character must be sent instead so that data is always being transmitted. Synchronous communication is usually more efficient because only data bits are transmitted between sender and receiver, and synchronous communication can be more costly if extra wiring and circuits are required to share a clock signal between the sender and receiver.

Implementation:

The structure of the laboratory 1 is simple and looks like this:



Here below i have the header of the UART driver that includes the prototipes of 3 funcions:


- Initialization
- Output character
- Input character

```
uart_stdio.h × uart_stdio.c
                          main.c


    → G:\Mega\UTM\PAllP\Lab1\Lab1\La

uart_stdio.h
     1 ⊡/*
          * uart_stdio.h
     3
         * Created: 06.10.2016 22:36:00
          * Author: Danny Ciobanu
     5
     6
     7
     8
     9 ⊟#ifndef UART STDIO H
         #define UART_STDIO_H_
    10
    11
         #define F_CPU 1000000UL
    12
    13
         #include <stdio.h>
    15  void uart_stdio_Init(void);
    int uart PutChar(char c, FILE *stream);
    17
         char uart_ReadChar();
    18
    19
         #endif /* UART_STDIO_H_ */
```

The scheme in Proteus:



The Result(Virtual Terminal):



Conclusion:

This laboratory work provides us with the knowledge of the input/output drivers used by Atmega32 MCU. Also we learned the architecture and design of this MCU and gained the possibility of using more interesting feature and functions.

Appendix:

```
uart stdio.h
#ifndef UART STDIO H
#define UART_STDIO_H_
#define F CPU 1000000UL
#include <stdio.h>
void uart_stdio_Init(void);
int uart PutChar(char c, FILE *stream);
char uart ReadChar();
#endif /* UART_STDIO H */
uart_stdio.c
#include "Header Files/uart stdio.h"
#define UART_BAUD 9600
#include <avr/io.h>
#include <stdio.h>
FILE uart output = FDEV SETUP STREAM(uart PutChar, NULL,
FDEV SETUP WRITE);
FILE uart_input = FDEV_SETUP_STREAM(NULL, uart_ReadChar,
FDEV SETUP READ);
void uart stdio Init(void) {
     stdout = &uart output;
     stdin = &uart_input;
     #if F CPU < 2000000UL && defined(U2X)
     UCSRA = BV(U2X); /* improve baud rate error by using
2x clk */
     UBRRL = (F CPU / (8UL * UART BAUD)) - 1;
```

```
#else
     UBRRL = (F_CPU / (16UL * UART_BAUD)) - 1;
     #endif
     UCSRB = BV(TXEN) | BV(RXEN); /* tx/rx enable */
}
int uart_PutChar(char c, FILE *stream) {
     if (c == '\n')
     uart_PutChar('\r', stream);
     while (~UCSRA & (1 << UDRE));</pre>
     UDR = c;
     return 0;
}
char uart_ReadChar() {
     //Wait untill a data is available
     while(!(UCSRA & (1<<RXC)))</pre>
     {
           //Do nothing
     //Now USART has got data from host
     //and is available is buffer
     return UDR;
}
main.c
#include "Header Files/uart_stdio.h"
#include <util/delay.h>
int main(void) {
     uart_stdio_Init();
     //printf("System is on");
     while(1){
           _delay_ms(500);
           printf("Hello World!\r");
     }
     return 0;
}
```