

COM303: Digital Signal Processing

Lecture 17: Sampling and applications

overview

- raw sampling and aliasing
- ► DT processing of CT signals

Sinc Sampling


$$x[n] = \langle \operatorname{sinc}\left(\frac{t - nT_s}{T_s}\right), x(t) \rangle$$

Sinc Sampling

$$x[n] = (\operatorname{sinc}_{T_s} *x)(nT_s)$$


Sinc Sampling

$$x[n] = (\operatorname{sinc}_{T_s} *x)(nT_s)$$



Sinc Sampling for Ω_N -BL signals

$$x[n] = (\operatorname{sinc}_{T_s} *x)(nT_s) = T_s x(nT_s)$$



"Raw" sampling - can we always do that?

$$x[n] = x(nT_s)$$

$$x(t) \xrightarrow{T_s} x[n]$$

Remember the wagonwheel effect?

$$x(t) = e^{j\Omega_0 t} = e^{j2\pi F_0 t}$$

- lacktriangle always periodic, period $T_0=2\pi/\Omega_0=1/F_0$
- ► all angular speeds are allowed
- $FT \left\{ e^{j\Omega_0 t} \right\} = 2\pi \delta(\Omega \Omega_0)$
- ▶ bandlimited to Ω_0^+

$$x(t) = e^{j\Omega_0 t} = e^{j2\pi F_0 t}$$


- lacktriangle always periodic, period $T_0=2\pi/\Omega_0=1/F_0$
- ► all angular speeds are allowed
- $FT\left\{e^{j\Omega_0t}\right\} = 2\pi\delta(\Omega \Omega_0)$
- ▶ bandlimited to Ω_0^+

$$x(t) = e^{j\Omega_0 t} = e^{j2\pi F_0 t}$$

- lacktriangle always periodic, period $T_0=2\pi/\Omega_0=1/F_0$
- ► all angular speeds are allowed
- $\blacktriangleright \mathsf{FT}\left\{e^{j\Omega_0t}\right\} = 2\pi\delta(\Omega \Omega_0)$
- ▶ bandlimited to Ω_0^+

$$x(t) = e^{j\Omega_0 t} = e^{j2\pi F_0 t}$$

- lacktriangle always periodic, period $T_0=2\pi/\Omega_0=1/F_0$
- ► all angular speeds are allowed
- ightharpoonup FT $\left\{e^{j\Omega_0t}\right\}=2\pi\delta(\Omega-\Omega_0)$
- bandlimited to Ω_0^+



Raw samples of the continuous-time complex exponential

$$x[n] = e^{j\Omega_0 T_s n}$$


- raw samples are snapshots at regular intervals of the rotating point
- lacktriangledown resulting digital frequency is $\omega_0=\Omega_0\,T_s=2\pi(\,T_s/\,T_0)$

Raw samples of the continuous-time complex exponential


$$x[n] = e^{j\Omega_0 T_s n}$$

- ▶ raw samples are snapshots at regular intervals of the rotating point
- lacktriangleright resulting digital frequency is $\omega_0=\Omega_0\,T_s=2\pi(\,T_s/\,T_0)$


Easy: $T_s < T_0/2 \quad \Rightarrow \quad \omega_0 < \pi$




Tricky: $T_0/2 < T_s < T_0$ \Rightarrow $\pi < \omega_0 < 2\pi$




Tricky: $T_0/2 < T_s < T_0 \quad \Rightarrow \quad \pi < \omega_0 < 2\pi$




Tricky: $T_0/2 < T_s < T_0 \quad \Rightarrow \quad \pi < \omega_0 < 2\pi$




Tricky: $T_0/2 < T_s < T_0$ \Rightarrow $\pi < \omega_0 < 2\pi$




Tricky: $T_0/2 < T_s < T_0$ \Rightarrow $\pi < \omega_0 < 2\pi$




Tricky: $T_0/2 < T_s < T_0$ \Rightarrow $\pi < \omega_0 < 2\pi$




Trouble: $T_s > T_0 \quad \Rightarrow \quad \omega_0 > 2\pi$




Trouble: $T_s > T_0 \quad \Rightarrow \quad \omega_0 > 2\pi$




Trouble: $T_s > T_0 \implies \omega_0 > 2\pi$




Trouble: $T_s > T_0 \quad \Rightarrow \quad \omega_0 > 2\pi$




Trouble: $T_s > T_0 \implies \omega_0 > 2\pi$




Trouble: $T_s > T_0 \quad \Rightarrow \quad \omega_0 > 2\pi$





Aliasing





Aliasing



















































































Sampling a Sinusoid

sampling frequency	digital frequency	interpolation
$F_s > 2F_0$ $F_s = 2F_0$ $F_0 < F_s < 2F_0$ $F_s < F_0$	$0<\omega_0<\pi$ $\omega_0=\pi$ $\pi<\omega_0<2\pi$ $\omega_0>2\pi$	OK: $\hat{F}_0 = F_0$ OK (max frequency $\hat{F}_0 = F_s$) negative frequency: $\hat{F}_0 = F_0 - F_s$ full aliasing: $\hat{F}_0 = F_0 \mod F_s$







$$x(t) = \cos(6\pi t) \qquad (F_0 = 3Hz)$$




$$x(t) = \cos(6\pi t) \qquad (F_0 = 3Hz)$$




$$x(t) = \cos(6\pi t) \qquad (F_0 = 3Hz)$$




$$x(t) = \cos(6\pi t) \qquad (F_0 = 3Hz)$$




$$x(t) = \cos(6\pi t) \qquad (F_0 = 3Hz)$$






 $F_s = 2.9 Hz$

$$x(t) = \cos(6\pi t) \qquad (F_0 = 3Hz)$$



$$x(t) = \cos(6\pi t) \qquad (F_0 = 3Hz)$$



Raw-sampling an arbitrary signal

$$x_c(t) \longrightarrow x[n] = x_c(nT_s)$$


$$T_s$$

Raw-sampling an arbitrary signal

$$X_c(j\Omega)$$
 $X(e^{j\omega}) = ?$


Key idea

- pick T_s (and set $\Omega_N = \pi/T_s$)
- ▶ pick $\Omega_0 < \Omega_N$




Key idea


- pick T_s (and set $\Omega_N = \pi/T_s$)
- ▶ pick $\Omega_0 < \Omega_N$




- pick T_s (and set $\Omega_N = \pi/T_s$)
- ▶ pick $\Omega_0 < \Omega_N$



- pick T_s (and set $\Omega_N = \pi/T_s$)
- ▶ pick $\Omega_0 < \Omega_N$



- pick T_s (and set $\Omega_N = \pi/T_s$)
- ▶ pick $\Omega_0 < \Omega_N$



- pick T_s (and set $\Omega_N = \pi/T_s$)
- ▶ pick $\Omega_0 < \Omega_N$

$$Ae^{j\Omega_0 t} + Be^{j(\Omega_0 + 2\Omega_N)t}$$
 \longrightarrow $(A+B)e^{j\Omega_0 T_s n}$ T_s

outline: start with the inverse Fourier Transform


$$x[n] = x_c(nT_s) = \frac{1}{2\pi} \int_{-\infty}^{\infty} X_c(j\Omega) e^{j\Omega \, nT_s} d\Omega$$


and manipulate the integral until it looks like


$$x[n] = \frac{1}{2\pi} \int_{-\pi}^{\pi} f(\omega) e^{j\omega n} d\omega$$


frequencies $2\Omega_N$ apart will be aliased, so split the integration interval


$$x[n] = \frac{1}{2\pi} \int_{-\infty}^{\infty} X_c(j\Omega) e^{j\Omega \, nT_s} d\Omega$$
$$= \frac{1}{2\pi} \sum_{k=-\infty}^{\infty} \int_{(2k-1)\Omega_N}^{(2k+1)\Omega_N} X_c(j\Omega) e^{j\Omega \, nT_s} d\Omega$$














$$x[n] = \frac{1}{2\pi} \sum_{k=-\infty}^{\infty} \int_{(2k-1)\Omega_N}^{(2k+1)\Omega_N} X_c(j\Omega) e^{j\Omega \, nT_s} d\Omega$$

with a change of variable and using $e^{j(\Omega-2k\Omega_N)T_sn}=e^{j\Omega T_sn}$:

$$x[n] = \frac{1}{2\pi} \sum_{k=-\infty}^{\infty} \int_{-\Omega_N}^{\Omega_N} X_c(j(\Omega - 2k\Omega_N)) e^{j\Omega \, nT_s} d\Omega$$

$$=rac{1}{2\pi}\int_{-\Omega_N}^{\Omega_N}\left[\sum_{k=-\infty}^{\infty}X_c(j(\Omega-2k\Omega_N))
ight]e^{j\Omega\,nT_s}d\Omega$$

periodization of the spectrum; define:

$$\tilde{X}_c(j\Omega) = \sum_{k=-\infty}^{\infty} X_c(j(\Omega - 2k\Omega_N))$$


so that:


$$x[n] = rac{1}{2\pi} \int_{-\Omega_N}^{\Omega_N} ilde{X}_c(j\Omega) e^{j\Omega T_s n} d\Omega$$


set $\omega = \Omega T_s$:


$$x[n] = \frac{1}{2\pi} \int_{-\pi}^{\pi} \frac{1}{T_s} \tilde{X}_c \left(j \frac{\omega}{T_s} \right) e^{j\omega n} d\omega$$
$$= IDTFT \left\{ \frac{1}{T_s} \tilde{X}_c \left(j \frac{\omega}{T_s} \right) \right\}$$


$$X(e^{j\omega}) = \frac{1}{T_s} \sum_{k=-\infty}^{\infty} X_c \left(j \frac{\omega}{T_s} - j \frac{2\pi k}{T_s} \right)$$
$$= \frac{\pi}{\Omega_N} \sum_{k=-\infty}^{\infty} X_c \left(j \frac{\omega \Omega_N}{\pi} - 2jk\Omega_N \right)$$












































- ▶ if the signal is bandlimited to π/T_s or less, raw sampling is fine (i.e. equivalent to sinc sampling up to a scaling factor T_s)
- ▶ if the signal is not bandlimited, two choices:
 - bandlimit via a lowpass filter in the continuous-time domain before sampling (i.e. sinc sampling)
 - or, raw sample the signal and incur aliasing
- aliasing introduces errors we cannot control, so the sensible choice is to bandlimit in continuous time
- bandlimiting is also optimal wrt least squares approximation

- ▶ if the signal is bandlimited to π/T_s or less, raw sampling is fine (i.e. equivalent to sinc sampling up to a scaling factor T_s)
- ▶ if the signal is not bandlimited, two choices:
 - bandlimit via a lowpass filter *in the continuous-time domain* before sampling (i.e. sinc sampling)
 - or, raw sample the signal and incur aliasing
- aliasing introduces errors we cannot control, so the sensible choice is to bandlimit in continuous time
- bandlimiting is also optimal wrt least squares approximation!

- ▶ if the signal is bandlimited to π/T_s or less, raw sampling is fine (i.e. equivalent to sinc sampling up to a scaling factor T_s)
- ▶ if the signal is not bandlimited, two choices:
 - bandlimit via a lowpass filter in the continuous-time domain before sampling (i.e. sinc sampling)
 - or, raw sample the signal and incur aliasing
- aliasing introduces errors we cannot control, so the sensible choice is to bandlimit in continuous time
- bandlimiting is also optimal wrt least squares approximation!

- ▶ if the signal is bandlimited to π/T_s or less, raw sampling is fine (i.e. equivalent to sinc sampling up to a scaling factor T_s)
- ▶ if the signal is not bandlimited, two choices:
 - bandlimit via a lowpass filter in the continuous-time domain before sampling (i.e. sinc sampling)
 - or, raw sample the signal and incur aliasing
- aliasing introduces errors we cannot control, so the sensible choice is to bandlimit in continuous time
- bandlimiting is also optimal wrt least squares approximation!

- ▶ if the signal is bandlimited to π/T_s or less, raw sampling is fine (i.e. equivalent to sinc sampling up to a scaling factor T_s)
- ▶ if the signal is not bandlimited, two choices:
 - bandlimit via a lowpass filter in the continuous-time domain before sampling (i.e. sinc sampling)
 - or, raw sample the signal and incur aliasing
- aliasing introduces errors we cannot control, so the sensible choice is to bandlimit in continuous time
- bandlimiting is also optimal wrt least squares approximation!

Sampling strategies

given a sampling period T_s

- ▶ if the signal is bandlimited to π/T_s or less, raw sampling is fine (i.e. equivalent to sinc sampling up to a scaling factor T_s)
- ▶ if the signal is not bandlimited, two choices:
 - bandlimit via a lowpass filter in the continuous-time domain before sampling (i.e. sinc sampling)
 - or, raw sample the signal and incur aliasing
- aliasing introduces errors we cannot control, so the sensible choice is to bandlimit in continuous time
- bandlimiting is also optimal wrt least squares approximation!

Sinc Sampling and Interpolation

$$\hat{x}[n] = \langle \operatorname{sinc}\left(\frac{t - nT_s}{T_s}\right), x(t) \rangle = (\operatorname{sinc}_{T_s} * x)(nT_s)$$

Sinc Sampling and Interpolation


$$\hat{x}[n] = \langle \operatorname{sinc}\left(\frac{t - nT_s}{T_s}\right), x(t) \rangle = (\operatorname{sinc}_{T_s} * x)(nT_s)$$


$$\hat{x}(t) = \sum_{n} x[n] \operatorname{sinc}\left(\frac{t - nT_s}{T_s}\right)$$


Sinc Sampling and Interpolation


$$\hat{x}[n] = \langle \operatorname{sinc}\left(\frac{t - nT_s}{T_s}\right), x(t) \rangle = (\operatorname{sinc}_{T_s} * x)(nT_s)$$


$$\hat{x}(t) = \sum_{n} x[n] \operatorname{sinc}\left(\frac{t - nT_s}{T_s}\right)$$


































Overview:


- ► Impulse invariance
- Duality
- Examples


Overview:


- ► Impulse invariance
- ▶ Duality
- Examples

Overview:


- ► Impulse invariance
- ▶ Duality
- ► Examples








assume $x_c(t)$ is Ω_N -bandlimited:



assume $x_c(t)$ is Ω_N -bandlimited:


$$X(e^{j\omega}) = \frac{1}{T_s} X_c \left(j \frac{\omega}{T_s} \right)$$



assume $x_c(t)$ is Ω_N -bandlimited:

$$X(e^{j\omega}) = \frac{1}{T_s} X_c \left(j \frac{\omega}{T_s} \right)$$

$$Y(e^{j\omega}) = X(e^{j\omega}) H(e^{j\omega})$$



assume $x_c(t)$ is Ω_N -bandlimited:


$$X(e^{j\omega}) = \frac{1}{T_s} X_c \left(j \frac{\omega}{T_s} \right)$$


$$Y(e^{j\omega}) = X(e^{j\omega}) H(e^{j\omega})$$


$$Y_c(j\Omega) = T_s Y(e^{j\Omega T_s})$$


$$Y_c(j\Omega) = X_c(j\Omega) H(e^{j\pi\Omega/\Omega_N})$$


$$H_c(j\Omega) = H(e^{j\pi\Omega/\Omega_N})$$

















Example

design a discrete-time filter to isolate a band of frequencies between 4000 and 5000Hz; input signals are bandlimited to 7KHz.

Example

- ▶ 7KHz band limit ⇒ we can use any sampling frequency above 14KHz
- ightharpoonup pick $F_s=16KHz$ so that $\Omega_N=2\pi\cdot 8000$ rad/s
- ▶ we need a bandpass with a 1000Hz bandwidth
- ▶ start with a lowpass with cutoff 500Hz
- ▶ modulate it to center it around 4500Hz


- ▶ 7KHz band limit ⇒ we can use any sampling frequency above 14KHz
- pick $F_s = 16 KHz$ so that $\Omega_N = 2\pi \cdot 8000 \text{ rad/s}$
- ▶ we need a bandpass with a 1000Hz bandwidth
- ▶ start with a lowpass with cutoff 500Hz
- ▶ modulate it to center it around 4500Hz

- ▶ 7KHz band limit ⇒ we can use any sampling frequency above 14KHz
- pick $F_s = 16 KHz$ so that $\Omega_N = 2\pi \cdot 8000 \text{ rad/s}$
- ▶ we need a bandpass with a 1000Hz bandwidth
- ▶ start with a lowpass with cutoff 500Hz
- ▶ modulate it to center it around 4500Hz


- ▶ 7KHz band limit ⇒ we can use any sampling frequency above 14KHz
- pick $F_s = 16 KHz$ so that $\Omega_N = 2\pi \cdot 8000 \text{ rad/s}$
- ▶ we need a bandpass with a 1000Hz bandwidth
- ▶ start with a lowpass with cutoff 500Hz
- ▶ modulate it to center it around 4500Hz

- ▶ 7KHz band limit ⇒ we can use any sampling frequency above 14KHz
- pick $F_s = 16 KHz$ so that $\Omega_N = 2\pi \cdot 8000 \text{ rad/s}$
- ▶ we need a bandpass with a 1000Hz bandwidth
- ▶ start with a lowpass with cutoff 500Hz
- ▶ modulate it to center it around 4500Hz


Impulse invariance



Impulse invariance



Impulse invariance



$$\omega_c = \pi \frac{\Omega_c}{\Omega_N} = \pi \frac{500}{8000} = 0.0625\pi$$

- $\omega_0 = \pi \frac{4500}{8000} = 0.5625\pi$
- lacktriangle design an FIR lowpass with cutoff ω_c using your favorite method
- ▶ multiply the impulse response by $2\cos\omega_0 n$

•
$$\omega_c = \pi \frac{\Omega_c}{\Omega_N} = \pi \frac{500}{8000} = 0.0625\pi$$


- $\omega_0 = \pi \frac{4500}{8000} = 0.5625\pi$
- lacktriangle design an FIR lowpass with cutoff ω_c using your favorite method
- ▶ multiply the impulse response by $2\cos\omega_0 n$


$$\omega_c = \pi \frac{\Omega_c}{\Omega_N} = \pi \frac{500}{8000} = 0.0625\pi$$


- $\omega_0 = \pi \frac{4500}{8000} = 0.5625\pi$
- lacktriangle design an FIR lowpass with cutoff ω_c using your favorite method
- ▶ multiply the impulse response by $2\cos\omega_0 n$

$$\omega_c = \pi \frac{\Omega_c}{\Omega_N} = \pi \frac{500}{8000} = 0.0625\pi$$


- $\omega_0 = \pi \frac{4500}{8000} = 0.5625\pi$
- lacktriangle design an FIR lowpass with cutoff ω_c using your favorite method
- ▶ multiply the impulse response by $2\cos\omega_0 n$








we can pick any T_s so pick $T_s = 1$:




we can pick any T_s so pick $T_s = 1$:

$$X_c(j\Omega) = X(e^{j\Omega})$$



we can pick any T_s so pick $T_s = 1$:

- $X_c(j\Omega) = X(e^{j\Omega})$
- $Y_c(j\Omega) = X_c(j\Omega)H_c(j\Omega)$





we can pick any T_s so pick $T_s = 1$:


- $X_c(j\Omega) = X(e^{j\Omega})$
- $Y_c(j\Omega) = X_c(j\Omega)H_c(j\Omega)$
- ullet LTI systems cannot change the bandwidth $\Rightarrow Y(e^{j\omega}) = Y_c(j\omega)$


$$Y(e^{j\omega}) = X(e^{j\omega}) H_c(j\omega)$$


$$H(e^{j\omega})=H_c(j\omega)$$













$$H(e^{j\omega})=e^{-j\omega d}$$

- ▶ if $d \in \mathbb{Z}$, simple delay
- ▶ if $d \notin \mathbb{Z}$, $h[n] = \operatorname{sinc}(n-d)$...


By duality





By duality





- $Y_c(j\Omega) = e^{-j\Omega d} X_c(j\Omega)$
- $y_c(t) = x_c(t-d)$
- ightharpoonup y[n] is the sampled interpolation of x[n] delayed by d















- ▶ to delay a discrete-time signal by a fraction of a sample we need an ideal filter!
- efficient approximations exist (e.g. cubic local interpolation)

Example: differentiator


$$H(e^{j\omega})=j\omega$$

- lacksquare in continuous time we know that FT $\{x_c'(t)\}=j\Omega\,X_c(j\Omega)$
- ▶ in discrete time...

By duality



By duality




- $Y_c(j\Omega) = j\Omega X_c(j\Omega)$
- $y_c(t) = x'_c(t)$
- y[n] is the sampled interpolation of x[n], differentiated

Digital differentiator, magnitude response

 $-\pi/2$


 $-\pi$



 $\pi/2$

Digital differentiator, phase response






Digital differentiator, impulse response

$$h[n] = \frac{1}{2\pi} \int_{-\pi}^{\pi} j\omega e^{j\omega n} d\omega$$

$$= \dots (integration by parts) \dots$$

$$= \begin{cases} 0 & n = 0 \\ \frac{(-1)^n}{n} & n \neq 0 \end{cases}$$

Digital differentiator, impulse response



Digital differentiator

- ▶ the digital differentiator is again an ideal filter!
- ▶ many approximations exist, with different properties

Wrap up

- ► Continuous-time processing of discrete-time sequences
- Discrete-time processing of continuous-time signals
- ▶ Jumping back and forth using sampling and interpolation
- ▶ In practice: Many applications of processing continuous-time signals in discrete time!