

Project HELIOS: Comprehensive Environment, Health, and Safety (EHS) Management Report

1. EHS Management Overview

The Environment, Health, and Safety (EHS) management framework for utility-scale Solar Photovoltaic (PV) Engineering, Procurement, and Construction (EPC) projects is a highly structured, multi-disciplinary system designed to mitigate risks to workers, local communities, and the ecosystem. On a large-scale project such as the 100 MW HELIOS facility and its associated 33/220kV Grid Substation (GSS) in Uzbekistan, EHS management must reconcile international lender requirements with national statutory regulations to secure ongoing project financing and legal compliance.

1.1 Role and Authority of the EHS Manager (AEGIS)

The Senior EHS Manager functions as the paramount authority regarding site safety and environmental compliance. Reporting directly to the Project Director and the corporate HSE steering committee, the EHS Manager possesses absolute Stop Work Authority (SWA). This authority empowers the EHS Manager to halt any construction activity, without financial or schedule penalty to the HSE department, if an imminent threat to life, health, or the environment is identified. The EHS Manager holds the authority to revoke site access for any personnel, mandate the immediate quarantine of defective equipment, and veto Method Statements or Risk Assessments that fail to meet the project's EHS thresholds. The role is not merely advisory; it acts as an independent regulatory function within the EPC structure, ensuring that schedule pressures do not override safety protocols.

1.2 The HSE Plan

The HSE Plan is the foundational governance document for the project. It is authored by the EPC Contractor's EHS Manager, reviewed by the Owner's Engineer (OE) or Independent Engineer (IE), and ultimately approved by the Client and Lender Technical Advisors. The plan establishes the baseline for all subsequent site-specific procedures and operationalizes the corporate HSE policy into actionable site metrics.

A comprehensive HSE Plan structure encompasses leadership commitment, legal requirements (integrating the Uzbekistan Labour Code, SanPiN standards, and IFC Performance Standards), and detailed risk management methodologies such as Job Safety Analysis (JSA). It dictates the operational controls for high-risk activities, outlines the Permit to Work (PTW) and Lockout/Tagout (LOTO) protocols, and establishes competence training matrices. Furthermore, it defines incident management timelines, site-specific emergency response plans, and the rigorous audit schedules required to maintain compliance¹.

1.3 The HSE Management System (HSE MS)

The HSE Management System for a large construction project is an iterative framework

operating on the Plan-Do-Check-Act (PDCA) cycle, compliant with ISO 45001 (Occupational Health and Safety) and ISO 14001 (Environmental Management)³. The system consists of documented policies, standard operating procedures (SOPs), physical control measures (such as edge protection and local exhaust ventilation), administrative controls (such as the PTW system), and continuous monitoring mechanisms. ISO 45001 requires that hazards are identified proactively, controls follow a strict hierarchy (Elimination, Substitution, Engineering, Administrative, Personal Protective Equipment), and that workers are consulted in safety decisions, ensuring a participatory safety culture rather than a purely punitive one².

1.4 IFC Performance Standards Context

For lender-financed projects, compliance with the International Finance Corporation (IFC) Performance Standards is mandatory and subject to regular third-party audits⁵. The core standards relevant to the HELIOS project include:

- **PS1: Assessment and Management of Environmental and Social Risks and Impacts:** Requires a dynamic Environmental and Social Management System (ESMS) that identifies project risks, mandates stakeholder engagement, and requires ongoing monitoring throughout the construction lifecycle. It demands that the EPC contractor does not merely react to incidents but proactively manages a live risk register¹.
- **PS2: Labour and Working Conditions:** Governs fair treatment, non-discrimination, and equal opportunity. It strictly prohibits child and forced labour, which is particularly scrutinized in Uzbekistan given historical agricultural labor practices⁷. PS2 requires working hours to align with national law (the Uzbekistan Labour Code limits standard work to 40 hours per week and caps overtime)⁹ and mandates a worker grievance mechanism that allows for anonymous complaints without retaliation¹⁰.
- **PS4: Community Health, Safety, and Security:** Mandates the protection of local communities from construction impacts, including traffic accidents, dust inhalation, and communicable diseases brought by the influx of transient workers. Crucially, PS4 dictates that security personnel must be unarmed unless a specific, documented threat necessitates armed guards, and strict rules of engagement and human rights training must be enforced for all security staff¹¹.

2. Permit to Work (PTW) System — Full Detail

The Permit to Work (PTW) system is the most critical administrative control on a utility-scale solar site. It is a formal, documented process utilized to control high-risk activities, ensuring that hazards are systematically identified, risk mitigation measures are implemented, and communication occurs between the individuals executing the work and those controlling the site. The system prevents conflicting activities—such as hot works occurring directly above flammable chemical storage—and ensures strict accountability by requiring physical signatures before hazardous energy is engaged or dangerous environments are entered.

2.1 Types of Permits and Operational Requirements

The following table details the exhaustive requirements for the primary permits utilized during the HELIOS project construction and commissioning phases.

Permit Type	Triggering Conditions	Required Precautions & Pre-Issue Checks	Issuer & Authorizer	Duration & Renewal
General Work	Routine construction (e.g., fencing, cable pulling) requiring formal area handover.	Standard PPE, area barricading. Check: PTRAs complete, workers inducted.	Issuer: Area Supervisor Auth: Safety Officer	1 shift (max 12h). Renewed daily.
Hot Work	Welding, grinding, oxy-cutting, or any activity generating sparks/flames.	Remove combustibles (10m radius), deploy fire blankets, continuous fire watch, 9kg DCP extinguishers. Check: Equipment integrity (flashback arrestors), wind speed limits.	Issuer: Area Authority Auth: EHS Manager / Hot Work Coordinator	1 shift. Suspended if wind > 10m/s.
Working at Height	Work ≥1.8m above ground, or near unguarded edges (substation gantries).	100% tie-off, certified anchor points (22kN), double lanyard harnesses, inspected scaffolding. Check: Harness visual inspection,	Issuer: WARDEN/GUARDIAN Auth: EHS Manager	1 shift.

		green scaffold tags, weather assessment ² .		
Excavation	Breaking ground >0.3m depth (cable trenches, GSS foundations).	Underground utility scans (GPR), shoring/benching for depths >1.2m, ladders every 7.5m, edge protection. Check: Soil class, spoil pile ≥1m from edge, utility drawings.	Issuer: Civil Manager Auth: GUARDIAN	Up to 7 days, subject to daily inspection.
Electrical (LV/HV)	Installation, testing, or maintenance on potentially live systems (combiner boxes, 33kV/220kV).	Strict LOTO protocol, zero energy verification, insulated tools, arc flash PPE (ATPV rated). Check: LOTO log verified, zero-energy test witnessed ² .	Issuer: Authorized Electrical Person (AEP) Auth: WARDEN	Task duration (max 1 shift).
Confined Space	Entry into spaces not designed for continuous occupancy (transformer oil pits, deep manholes).	Atmospheric gas testing (O2, LEL, H2S, CO), forced ventilation, standby rescue person, retrieval tripod/winch. Check: Gas	Issuer: AEP / Civil Manager Auth: EHS Manager only	1 shift. Voided if evacuated.

		detector calibration, rescue gear deployed.		
Lifting Operations	Operation of mobile cranes, tower cranes, or HIABs for material movement.	Engineered lifting plan, outrigger mats, standard communication (radios/hand signals), barricaded exclusion zones. Check: Crane 3rd-party cert, rigging hardware color-coded, wind check.	Issuer: Appointed Person for Lifting Auth: GUARDIAN/WARDEN	Specific lift or series in 1 shift.

2.2 Lockout Tagout (LOTO) Procedure

LOTO is a critical safety procedure utilized to ensure that dangerous machines and energy sources are properly shut off and incapable of being energized prior to the completion of maintenance or servicing work. In a 33/220kV GSS environment, LOTO failure is the primary cause of fatal electrocution and arc flash incidents.

The full LOTO procedure for a 33kV electrical circuit on a solar site involves sequential, highly controlled steps. First, the Authorized Electrical Person (AEP) identifies all energy sources, including primary AC/DC, back-up UPS, and stored mechanical energy in breaker springs. All affected personnel in the substation are formally notified of the impending isolation. The equipment is powered down using standard operating procedures, and the main circuit breakers and disconnect switches are opened. In high-voltage environments, a trapped key interlock system is frequently utilized to ensure operations follow a strict mechanical sequence (e.g., ensuring a tie-breaker cannot be closed unless main breakers are locked open)¹³.

Once isolated, personal padlocks are applied to the isolation points. A multi-hasp is utilized if multiple workers are involved, ensuring the system cannot be energized until every single worker has removed their personal lock. High-visibility warning tags are attached, stating "DANGER - DO NOT OPERATE," displaying the worker's name, date, and contact information. Crucially, grounding switches must be closed to discharge any trapped capacitance or residual charge in the HV lines, which can hold lethal energy even after disconnection¹⁴. The final step is the "Test Before Touch" verification: a certified voltage detector is tested on a known live

source, then used to verify zero energy on the isolated equipment, and tested again on the live source to ensure instrument functionality. Only after this verification can work proceed.

2.3 Live-Line Work Permit

Live-line work permits are strictly controlled exceptions utilized only when de-energizing introduces greater hazards or is technically impossible during grid synchronization and energization. These permits are triggered by energized testing, commissioning measurements, or highly specialized maintenance.

Special precautions mandate strict adherence to Minimum Approach Distances (MAD) based on IEEE 516 and OSHA 1910.269 standards, which calculate safe distances based on voltage phase-to-ground characteristics¹⁵. Personnel must utilize specialized arc-flash suits (cal/cm² rated), dielectric gloves (Class 00 to Class 4 depending on voltage), and insulated hot sticks. Due to the extreme risk, authorization requires joint approval from the Project Director and the Senior EHS Manager, with a dedicated safety observer stationed outside the arc flash boundary holding an insulated rescue hook.

3. Daily EHS Workflow

3.1 The EHS Officer's Daily Routine

The daily routine of an EHS Officer (GUARDIAN/WARDEN agents) ensures continuous field presence and proactive hazard mitigation, establishing the safety culture through visibility and immediate intervention.

The day begins prior to site opening, typically at 06:30, with a review of overnight security logs and weather forecasts. High winds or extreme temperatures will dictate which permits are suspended. At 07:00, the officers attend subcontractor Toolbox Talks (TBTs) and review and authorize daily PTWs and Pre-Task Risk Assessments (PTRAs) at the permit office. From 08:00 to 12:00, the officers conduct dynamic inspections of high-risk activities at the workplace—such as lifting operations or trenching—verifying that the conditions specified on the PTW match the physical reality. Unsafe acts are corrected immediately through coaching or work stoppage. During the mid-day hours, particularly critical during the Uzbekistan summer when temperatures exceed 45°C, officers monitor rest areas to ensure adequate shade and hydration provisions are actively maintained in compliance with SanPiN heat stress limits⁷. The afternoon consists of targeted thematic audits (e.g., inspecting all heavy plant machinery or verifying waste segregation) and engaging with workers on safety observations. The day concludes with PTW closure, ensuring all permits are signed off or properly suspended, compiling daily observation reports, and briefing the EHS Manager on systemic issues requiring higher-level intervention.

3.2 Daily Safety Inspection

A daily safety inspection is a structured observational patrol verifying that physical and administrative controls are functioning. It goes beyond a casual walkthrough, utilizing a standardized checklist to systematically evaluate access/egress routes, housekeeping standards, edge protection integrity, PPE compliance, plant and equipment condition, and environmental controls such as spill trays and dust suppression water bowsers. The form assigns responsible parties and strict closure timeframes for any identified deviations,

transforming observations into actionable accountability.

3.3 Toolbox Talk (TBT)

A TBT is a brief (10-15 minute) daily safety meeting conducted at the workplace prior to the shift. It is led by the site supervisor or foreman, supported by the EHS Officer. It serves to transition workers into a safety-oriented mindset before handling tools. Topics are highly specific to the day's tasks but follow a weekly thematic schedule to ensure comprehensive coverage over the project lifecycle (e.g., Monday: Hydration and Heat Stress; Tuesday: Hand Injuries and Pinch Points; Wednesday: Mobile Plant Blind Spots; Thursday: Working at Height; Friday: Housekeeping and Slip Hazards).

3.4 Pre-Task Risk Assessment (PTRA)

A PTRA (frequently termed a Job Safety Analysis or JSA) is a field-level, task-specific risk assessment completed by the work crew immediately before starting a task. The process requires the crew to physically look at their work area and map the sequence of basic task steps, identify the hazards associated with each step, and agree upon the control measures. Crucially, every crew member must sign the document, confirming their understanding of their specific role in mitigating the identified hazards.

3.5 Safety Observation System

Safety observations act as proactive leading indicators. Personnel are trained and encouraged to report both Unsafe Acts (e.g., a worker bypassing a machine guard) and Unsafe Conditions (e.g., a frayed electrical cable lying in a puddle), as well as Positive Observations. Observations are recorded on physical cards distributed across the site or via a digital application, categorized by hazard type, and actioned by supervisors. This data is aggregated monthly to identify systemic trends, allowing the EHS Manager to deploy targeted interventions before an incident occurs.

3.6 Stop Work Authority (SWA)

Stop Work Authority is the mandated right and obligation of every individual on site—from the Project Director to general laborers—to halt work if they observe a situation that creates an imminent danger to people, the environment, or equipment. When exercised, work ceases immediately, the area is secured, and the EHS team is notified. Work cannot resume until the hazard is rectified and the EHS Manager formally lifts the stop work order. Retaliation or intimidation against any worker invoking SWA is considered gross misconduct and is grounds for immediate termination from the project.

4. High-Risk Activity Management

Utility-scale solar projects introduce unique risk profiles due to the vast geographical spread of the site, the repetitive nature of the installation, and the handling of heavy, fragile components in open environments.

4.1 Pile Driving (Solar Module Foundations)

The foundation of a solar tracker or fixed-tilt system requires thousands of steel piles to be driven into the earth. This presents severe hazards regarding high noise levels, hand-arm vibration for operators, structural strikes, and the risk of striking underground utilities.

Supervision & Control: Operators must wear double hearing protection (plugs plus over-ear

muffs) to comply with the Uzbekistan noise limit standards (KMK 2.01.08-96)¹⁷. Strict exclusion zones, matching the height of the piling mast plus a safety margin (typically 5 meters), must be delineated using physical barriers. Method statements must detail underground scanning protocols using Ground Penetrating Radar (GPR) and machine stability checks on soft desert ground. The GUARDIAN safety officer must verify the utility clearance permit, ensure the exclusion zone is unbroken, and confirm the operator's daily pre-use machine checklist is complete.

4.2 Working at Height (Module Installation & Substation)

Falls from height remain the leading cause of fatalities in construction. On a solar site, this applies to substation roof works, structural steel erection, and module installation on heavily inclined terrain where a slip can result in a significant fall.

Supervision & Control: Following the hierarchy of controls², engineering controls such as perimeter guardrails are mandatory for substation structures. For module installation, fall restraint systems must be utilized to prevent workers from reaching the fall edge. Dropped object prevention, such as tool lanyards, is mandatory for all overhead works². The method statement must include a detailed rescue plan outlining the recovery of a suspended worker within 5 minutes to prevent suspension trauma². Supervisors must visually inspect harness tags, verify certified anchor points, and enforce drop-zone exclusion barricades.

4.3 Manual Handling (Module Installation)

Modern bifacial PV modules weigh upwards of 30kg to 35kg and possess large surface areas, making them highly susceptible to wind loading. This creates acute risks for musculoskeletal disorders, severe cuts from shattered glass, and crush injuries.

Supervision & Control: A mandatory two-person lift rule must be enforced for all modules. Specialized glass-handling suction cups should be provided to improve grip, and cut-resistant (ANSI Level A4 or higher) gloves are mandatory. The ergonomic handling plan must dictate the staging of modules to minimize carrying distance. Crucially, installation must be halted when wind speeds exceed the manufacturer's safe handling threshold (typically 10 m/s). Supervisors monitor lifting posture and mandate micro-breaks to prevent fatigue.

4.4 Lifting Operations (Crane Lifts)

Lifting heavy infrastructure, such as 220kV transformers or prefabricated switchgear modules, introduces catastrophic risks of crane tip-over, load drops, crushing, and overhead powerline strikes.

Supervision & Control: A "Critical Lift" is defined as any lift exceeding 75% of the crane's rated capacity, tandem lifts involving two cranes, or lifts over active infrastructure. These require a formal lifting plan approved by a certified Appointed Person. Continuous communication between the operator and the banksman is required, and taglines must be used to control the load's rotation. Supervisors must verify the crane's valid third-party certification, ensure outriggers are fully extended on engineered mats to distribute ground bearing pressure, and check that rigging hardware is color-coded for the current inspection period.

4.5 Excavation and Trenching

Trenching for DC and AC cabling networks across a 100 MW site involves miles of excavations,

presenting risks of trench collapse, asphyxiation, and striking buried services.

Supervision & Control: Any trench deeper than 1.2 meters requires engineered shoring, shielding (trench boxes), or battering/benching of the walls to prevent soil collapse. Ladders must be provided every 7.5 meters for rapid egress. Gas testing is required if the trench exceeds 1.2 meters in depth and is located near potential contaminant sources. The method statement must detail dewatering plans and spoil placement. The GUARDIAN officer must ensure spoil piles are kept a minimum of 1 meter from the edge to prevent surcharge loading, hard barricades are erected, and heavy plant offset distances are maintained.

4.6 Electrical Works (LV, MV, HV)

The energization of string combiner boxes, inverters, and the 33/220kV substation introduces the invisible hazards of arc flash and fatal electrocution.

Supervision & Control: Total reliance on the LOTO system is non-negotiable. Where testing live circuits is unavoidable, Minimum Approach Distances (MAD) must be maintained¹⁵.

Arc-flash boundaries must be calculated, and appropriate ATPV-rated Personal Protective Equipment must be worn². The WARDEN safety officer must verify that LOTO locks are in place, the Test-Before-Touch principle is demonstrated, insulated tools are utilized, and unauthorized personnel are cleared from the arc flash boundary.

4.7 Hot Works (Welding/Grinding)

Fabrication of structural steel and substation grounding grids involves welding and grinding, creating fire, explosion, toxic fume, and UV radiation hazards.

Supervision & Control: Hot work permits are mandatory. All flammable materials within a 10-meter radius must be removed. Fire-retardant blankets must be deployed to catch sparks. A designated fire watch, equipped with minimum 9kg dry chemical powder extinguishers, must be present during the work and for 30 minutes following its conclusion. Supervisors must ensure the welding machine is properly grounded, localized exhaust ventilation is used if in a confined area, and welding screens are erected to protect adjacent workers from UV flash or "arc eye."

5. Incident Management

5.1 Incident Classification System

Accurate classification dictates the reporting timeline and the depth of the subsequent investigation.

- **Fatality:** Death resulting from a work-related injury or occupational illness.
- **Lost Time Injury (LTI):** An injury preventing the worker from returning to their next scheduled shift, resulting in lost productive time.
- **Medical Treatment Case (MTC):** An injury requiring professional medical treatment beyond basic first aid (e.g., sutures, prescription medication, fracture immobilization).
- **First Aid Injury (FAI):** Minor injury treatable on-site by a medic or first-aider (e.g., minor cut, bandage, over-the-counter medication).
- **Near Miss:** An event that did not result in injury, illness, or damage, but had the potential to do so under slightly different circumstances.
- **Dangerous Occurrence:** A severe failure of safety systems or equipment (e.g., crane

collapse, scaffold failure, major structural collapse) that miraculously resulted in no injuries.

- **Property/Environmental Damage:** Financial loss due to equipment destruction or environmental impact (e.g., transformer oil spill).

5.2 Incident Reporting Process

The regulatory and lender reporting clocks begin the moment an incident occurs.

1. **Immediate Action:** Stop work, secure the scene to prevent secondary incidents, and provide first aid or medical evacuation.
2. **Initial Notification (Within 4-24 Hours):** A brief notification is provided to Project Management and the Client detailing what occurred, the time, location, and the immediate status of the injured party or asset¹⁸.
3. **Formal Notification (Within 48 Hours):** A comprehensive initial report is provided to the Client and Lenders. IFC requirements explicitly mandate the prompt reporting of significant incidents (fatalities, serious injuries, major spills) within 48 hours of occurrence²⁰.
4. **Investigation (Within 7-14 Days):** Execution of the Root Cause Analysis (RCA) and drafting of the final investigation report.
5. **Closure:** Implementation of the Corrective Action and Preventive Action (CAPA) plan and dissemination of lessons learned across the site via toolbox talks.

5.3 Incident Investigation Methodology

Depending on the severity or potential severity of the incident, different investigative methodologies are applied.

- **5-Why Analysis:** Utilized for lower-tier incidents. The investigator repeatedly asks "Why?" to drill down from the direct cause to the systemic root cause (e.g., Worker cut hand → Why? No gloves → Why? Not issued → Why? Inventory empty → Why? Procurement process failure).
- **Bow-Tie Analysis:** Utilized for high-potential incidents or dangerous occurrences. It visually maps a hazard, the preventive controls on the left side, the top event (the incident) in the center, the mitigative controls on the right side, and the ultimate consequences. This highlights exactly which specific barriers failed and which succeeded.
- **Fault Tree Analysis:** A top-down, deductive failure analysis using Boolean logic (AND/OR gates) to analyze how multiple independent failures combined to cause the catastrophic event.

5.4 Corrective Action and Preventive Action (CAPA)

CAPAs bridge the gap between incident investigation and systemic improvement, ensuring the organization learns from failure.

- **Format:** The CAPA register identifies the root cause, the required action (e.g., rewrite procedure, install guard), the person responsible, and a strict deadline.
- **Close-out Process:** Once the action is physically implemented, the EHS Manager must

verify its effectiveness in the field before formally signing off and closing the CAPA in the project register.

5.5 Key Performance Indicators (KPIs)

EHS performance is tracked using a blend of lagging and leading indicators.

- **Lagging Indicators:** Lost Time Injury Frequency Rate (LTIFR) and Total Recordable Injury Frequency Rate (TRIFR). These measure past failures and are calculated per 1,000,000 or 200,000 man-hours worked.
- **Leading Indicators:** Near-miss reporting rates, number of leadership site walks, PTW audit compliance scores, and the closure rate of unsafe act observations. These measure proactive safety culture and predict future performance.

6. Environmental Management (VERDANT Agent)

Utility-scale solar projects, while producing green energy, have substantial environmental footprints during the construction phase. In the arid, sensitive environments of Uzbekistan, ecological management is critical.

6.1 Environmental Aspects and Impacts

- **Land Disturbance & Dust:** The clearing of sparse desert vegetation for site grading destroys root systems, leading to severe topsoil erosion and massive particulate matter (dust) generation during wind events.
- **Noise and Vibration:** Piling operations, generators, and heavy plant traffic impact local fauna behavior and disturb nearby residential communities.
- **Water Consumption:** High water usage for dust suppression and concrete batching strains local, often scarce, aquifers and municipal supplies.
- **Chemical/Oil Spills:** Hydrocarbon leaks from heavy machinery, hydraulic line bursts, or catastrophic spills during transformer oil filling operations contaminate soil and groundwater.
- **Waste Generation:** Vast quantities of packaging (wood pallets, plastic wrap), damaged PV modules (containing heavy metals), and domestic waste from worker camps.
- **Biodiversity:** Disruption of local flora and fauna habitats through perimeter fencing, land grading, and increased human presence.

6.2 Environmental and Social Management Plan (ESMP)

The ESMP is the operationalization of the Environmental and Social Impact Assessment (ESIA) conducted prior to project approval. It structures the contractor's obligations.

- **Structure and Key Content:** The ESMP identifies the legal framework (Uzbekistan environmental laws and SanPiN standards) and applies the mitigation hierarchy: Avoid, Minimize, Restore, Offset. It contains detailed sub-plans for Dust, Waste, Spills, Water, and Biodiversity, and provides a Monitoring Matrix detailing what is monitored, acceptable limits, frequency, and responsibilities.

6.3 Environmental Monitoring Program

The VERDANT officer executes the monitoring program to ensure statutory limits are not breached.

- **Air Quality (Dust):** Monitored via stationary sensors at site boundaries. SanPiN 0293-11

sets Maximum Permissible Concentrations (MPC) for PM10 at 500 µg/m³²². Data is monitored continuously; exceedances trigger automatic increases in dust suppression activities.

- **Noise:** Monitored using hand-held, calibrated decibel meters at the site perimeter and nearest sensitive receptors. Uzbekistan standard KMK 2.01.08-96 mandates maximum continuous noise levels of 55 dBA during the day and 45 dBA at night in residential areas²³.
- **Spills and Waste:** Visual monitoring daily via the site inspection checklists.

6.4 Dust Suppression Management

In the arid desert and steppe conditions of Uzbekistan, dust management is paramount to maintain community relations and protect worker respiratory health. Controls include deploying a dedicated fleet of water bowsters to continuously spray haul roads and active earthworks areas. Strict site speed limits (e.g., 20 km/h) are enforced to minimize wheel-generated dust²⁴. On long-term static dirt roads, environmentally safe chemical dust suppressants (palliatives) may be applied to bind the soil. Crucially, bulk earthworks must be halted when wind speeds exceed safe operational limits²⁴.

6.5 Construction Waste Management

Waste management follows strict segregation and chain-of-custody protocols.

- **Categories & Segregation:** Mandatory multi-bin systems are deployed across the site. Categories include Hazardous (oil filters, contaminated rags, paint cans, damaged solar panels), Recyclable (wood pallets, cardboard, metals, uncontaminated plastics), and General Domestic waste.
- **Disposal:** Hazardous waste must be tracked via a chain-of-custody manifest. It can only be transported and disposed of by licensed facilities explicitly approved by the Uzbekistan Ministry of Ecology, Environmental Protection and Climate Change²⁵.

6.6 Chemical/Oil Spill Response Plan

The plan focuses on prevention through secondary containment—requiring bunding that holds 110% of the largest vessel's volume—and the mandatory use of drip trays under all static plant (e.g., diesel generators). In the event of a spill, the response protocol is:

1. Stop the source (e.g., plug the leak, upright the drum).
2. Contain the spill using booms and absorbent granules from strategically placed, highly visible spill kits.
3. Clean up the material and place contaminated soil and absorbents into designated hazardous waste bags.
4. Report the volume and specific GPS location to the VERDANT Environmental Officer for logging and remediation verification.

6.7 Biodiversity and Habitat Management

Prior to civil works, ecological sweep surveys are conducted to identify and relocate critical species (e.g., specific reptiles or nesting birds). The plan enforces a strict prohibition on hunting, poaching, or feeding wildlife by the workforce. "No-Go" ecological buffer zones are delineated with high-visibility fencing to prevent unauthorized machinery encroachment into

sensitive habitats or watercourses.

7. Social Management (VERDANT Agent)

International lenders scrutinize the social impact of utility-scale infrastructure as heavily as the environmental impact. The VERDANT agent manages the interface between the project and the local population.

7.1 Grievance Mechanism

Lender-financed projects require a robust Grievance Redress Mechanism (GRM) in accordance with IFC PS2 (for workers) and PS4 (for communities)¹⁰.

- **Setup:** The GRM provides easily accessible, multi-lingual intake channels, including locked drop boxes at site gates, dedicated hotlines, WhatsApp numbers, and physical community liaison offices.
- **Operation:** The system guarantees confidentiality and strictly prohibits retaliation against complainants¹⁰.
- **Resolution Framework:** Grievances must be formally acknowledged within 7 days. Investigation and proposed resolution must be communicated to the complainant within 14 to 30 days, depending on the complexity of the issue. An appeals process must be available.

7.2 Community Liaison

Remote projects require active community management to maintain a "social license to operate." Community Liaison Officers (CLOs) act as the bridge between the EPC contractor and the local Makhalla (traditional community councils)²⁷. CLOs proactively communicate disruptive construction schedules (e.g., heavy transport convoys causing traffic, noisy piling operations). They manage local employment expectations by transparently communicating hiring processes, and they address community grievances regarding dust or road damage before they escalate to protests or blockades.

7.3 Labour Standards (IFC PS2 & Uzbekistan Law)

The project must strictly adhere to both IFC PS2 and the national labor code.

- **Working Hours:** Monitored to comply with the Uzbekistan Labour Code (40-hour standard week) and stringent statutory overtime caps to prevent fatigue-related accidents⁹. Mandatory weekly rest days must be provided.
- **Wages:** Payment must meet minimum wage laws, be paid in full, on time, and directly to the worker with transparent, understandable payslips.
- **Forced and Child Labour:** There is an absolute zero-tolerance policy for forced labour, bonded labour, or the employment of minors (under 18 for hazardous construction work)⁷. This is particularly critical in Uzbekistan, where international scrutiny on agricultural labor practices means lenders demand rigorous subcontractor audits to verify age documentation and ensure employers are not withholding worker passports (a common indicator of bonded labor).

7.4 Stakeholder Engagement Plan (SEP)

The SEP is a formal document identifying all project stakeholders, mapping them by influence

and interest (e.g., local residents, regional government ministries, environmental NGOs, lenders). It outlines the frequency, format, and content of communications, ensuring stakeholders are informed of project impacts, employment opportunities, and mitigation measures well in advance of the mobilization phase.

8. Emergency Response

The Emergency Response Plan (ERP) provides the structured, rapid-reaction framework necessary to manage crisis events on a remote site where municipal emergency services may be hours away.

8.1 Emergency Response Plan (ERP) Structure

A comprehensive ERP includes:

1. **Objective and Scope:** Defining the boundaries of the plan.
2. **Chain of Command:** Establishing the Incident Commander and defining specific roles (e.g., Fire Wardens, First Aiders).
3. **Communication Protocols:** Internal radio channels and external emergency service contact trees.
4. **Evacuation and Muster Procedures:** Routes, assembly points, and accounting methodologies.
5. **Specific Emergency Scenarios:** Step-by-step action cards for distinct crises.
6. **Resource Inventory:** Location maps of first aid stations, rescue equipment, and fire suppression gear.
7. **Training and Drill Schedule:** Mandating quarterly full-scale evacuation drills.

8.2 Emergency Scenarios

The ERP must contain specific tactical plans for:

- **Fire:** Immediate evacuation, isolation of electrical sources, deployment of trained personnel with fire extinguishers, and coordination with local fire brigades.
- **Medical Emergency:** Immediate first aid by trained personnel, stabilization, and rapid transport via site ambulance to pre-vetted local hospitals.
- **Chemical/Oil Spill:** Activation of the spill response team, deployment of heavy containment booms, and prevention of waterway contamination.
- **Structural Collapse / Trench Cave-in:** Immediate stop work, securing the perimeter, and deployment of specialized confined space/trench rescue teams (standard personnel are prohibited from entering a collapsed trench to attempt rescue).
- **Vehicle Accident:** Scene security, traffic diversion, extraction of injured parties, and spill containment.

8.3 Muster Point System and Headcount

In an emergency, a continuous blast of the site air-horns triggers evacuation. All personnel drop their tools, make their immediate area safe (e.g., turn off acetylene torches), and proceed via safe routes to designated, highly visible Muster Points located in safe zones. Area Supervisors conduct immediate roll calls, cross-referencing against the daily PTW logs and gate access control data. The Incident Commander is notified of any missing personnel, which directs the search and rescue teams.

8.4 First Aid Requirements

- **Personnel:** A minimum ratio of 1 certified first aider per 25 workers is maintained on site at all times.
- **Kits:** Fully stocked trauma kits, regularly audited for expired items, are available at all active workfronts and in supervisor vehicles.
- **Medical Facilities:** For a massive 100 MW site spanning hundreds of hectares, a dedicated site clinic staffed by a registered nurse or paramedic is mandatory. A dedicated 4x4 ambulance, capable of navigating rough, unpaved site terrain, must be on standby for immediate medical evacuation to local hospitals.

9. Real Document Templates — Full Detail

The following structured templates form the administrative backbone of the HSE Management System for Project HELIOS.

9.1 HSE Plan — Full Table of Contents

Section	Title	Sub-Sections
1.0	Introduction & Scope	Project description (100MW HELIOS), Objectives, Corporate HSE Policy
2.0	Leadership & Accountability	Organizational chart, EHS Manager authority (SWA), KPI targets (LTIFR)
3.0	Legal & Lender Requirements	Uzbek Labour Code, SanPiN, IFC PS 1/2/4, Equator Principles, ISO 45001
4.0	Risk Management	Hazard Identification, JSA methodology, PTR matrix, Hierarchy of controls
5.0	Competence & Training	Site induction, TBT schedules, specialized training (WAH, LOTO, Confined Space)
6.0	Communication &	Worker committees, Safety

	Consultation	observation reporting, Grievance Mechanism (GRM)
7.0	Operational Controls	PTW system, High-risk activity management, Subcontractor auditing
8.0	Occupational Health	Heat stress management (SanPiN 0289-10), First aid, Fitness to work, Ergonomics
9.0	Environmental & Social	Dust (SanPiN 0293-11), Waste segregation, Spills, Biodiversity, Community liaison
10.0	Emergency Response	Evacuation routes, Scenario action plans, Drill schedule, Emergency contacts
11.0	Incident Management	Reporting thresholds (48h IFC), Investigation methodologies (Bow-Tie, 5-Why)
12.0	Audit & Review	Daily/Weekly inspections, Lender audits, Management review meetings

9.2 Daily Safety Inspection Report

FIELD	DATA ENTRY / CHECKLIST
Date / Time:	2026-10-04 / 08:30
Inspector:	GUARDIAN (Safety Officer - Civil)

Location:	Zone C - Inverter Station 4 Foundation
Category - PPE:	☒ Compliant ☐ Non-Compliant - <i>Note: All workers wearing hardhats, glasses, and high-vis.</i>
Category - WAH:	☐ Compliant ☐ Non-Compliant ☒ N/A - <i>Note: No height work in this zone today.</i>
Category - Excavation:	☐ Compliant ☒ Non-Compliant - <i>Note: Spoil pile located within 0.5m of trench edge. Risk of surcharge collapse.</i>
Category - Lifting:	☒ Compliant ☐ Non-Compliant - <i>Note: Crane outriggers fully deployed on engineered timber mats.</i>
Category - Environment:	☐ Compliant ☒ Non-Compliant - <i>Note: Diesel generator drip tray overflowing with rainwater, risk of hydrocarbon run-off.</i>
Immediate Action Taken:	Halted excavation work. Directed excavator operator to push spoil pile back to minimum 1.5m offset.
Action Assigned To:	Civil Supervisor (J. Smith) for trench; Mech Supervisor (A. Ivanov) for drip tray.
Close-out Date:	2026-10-04 (Immediate for trench; End of shift for drip tray).

9.3 Toolbox Talk (TBT) Record

TBT Details	
Date: 2026-10-05	Supervisor: A. Ivanov
Topic: Working at Height - Substation	Duration: 15 Minutes

Steelwork	
Key Talking Points:	1. 100% tie-off required above 1.8m at all times. 2. Inspect harnesses for fraying, chemical burns, or deployed shock absorbers before use. 3. Dropped object hazard: Use tool lanyards for all spanners and impacts. 4. Identify certified anchor points (do not clip to cable trays).
Worker Signatures:	1. <i>[Signature]</i> 2. <i>[Signature]</i> 3. <i>[Signature]</i> 4. <i>[Signature]</i> 5. <i>[Signature]</i>

9.4 Hot Work Permit

Hot Work Permit	Permit No: HW-2026-142
Valid From: 2026-10-06 07:00	Valid To: 2026-10-06 17:00
Location: Substation 220kV Gantries	Task: Arc welding structural steel joints
Precautions Checklist:	☒ Combustibles cleared (10m radius) ☒ Fire-retardant blankets deployed ☒ Dedicated Fire Watch present (Name: B. Aliyev) ☒ 2 x 9kg DCP extinguishers present at workface
Gas Test (if applicable):	LEL: 0% / O2: 20.9% / H2S: 0ppm (Not a confined space, but near cable trenches)

Issuer (Supervisor):	Signature: <i>[Signature]</i>
Authorizer (EHS):	Signature: <i>[Signature]</i>
Closure Sign-off:	Work complete. 30-min continuous fire watch concluded without smoldering or incident. Signature: <i>[Signature]</i>

9.5 Working at Height Permit

Working at Height Permit	Permit No: WAH-2026-045
Valid From: 2026-10-07 08:00	Valid To: 2026-10-07 18:00
Location: Block 12, Tracker Row 4	Task: Installing Tracker Drive Motors
Precautions Checklist:	☒ Ground uneven; fall restraint required. ☒ Harnesses inspected (Green Tag valid). ☒ Tool lanyards in use. ☒ Wind speed verified < 10m/s.
Rescue Plan Verified:	☒ MEWP (Manlift) on standby for rapid suspended worker rescue.
Issuer (Supervisor):	Signature: <i>[Signature]</i>
Authorizer (EHS):	Signature: <i>[Signature]</i>

9.6 Electrical Work Permit (LV)

Electrical Work Permit (LV)	Permit No: ELV-2026-088
Task: Terminating String Combiner Box (SCB-12)	Max Voltage: 1500V DC

LOTO Verified: [X] Yes (Log #L-099)	Isolation Point: Inverter 4 DC Disconnect
Precautions:	[X] Insulated tools (1000V rated) inspected. [X] Arc Flash PPE (Class 2, 8 cal/cm ²) donned. [X] Test-Before-Touch protocol verified.
Authorized Elec. Person:	Signature: <i>[Signature]</i>
Authorizer (WARDEN):	Signature: <i>[Signature]</i>

9.7 HV Live-Line Permit

HV Live-Line Permit	Permit No: LL-2026-002
Location: 33kV Switchgear Room	Task: Phasing checks during grid sync
Justification:	Cannot be performed de-energized. Required for commissioning.
Precautions:	[X] MAD maintained (2.5 ft) ¹⁵ . [X] Arc flash suit (40 cal/cm ²) donned. [X] Class 4 dielectric gloves inspected/air-tested. [X] Safety observer with insulated rescue hook present.
Approvals Required:	EHS Manager: <i>[Signature]</i> Project Director: <i>[Signature]</i>

9.8 LOTO Procedure Log

Step	Action Description	Executed By	Time
------	--------------------	-------------	------

1	Inform area personnel of impending 33kV shutdown	AEP (M. Petrov)	08:00
2	Open Main Circuit Breaker (MCB) 01 locally	AEP	08:05
3	Apply Multi-Hasp, Personal Padlock (Red #42), and DANGER Tag	AEP	08:10
4	Rack breaker out to 'Test' then 'Isolated' position	AEP	08:12
5	Close Grounding Switch to discharge line capacitance	AEP	08:15
6	Voltage test on known live source (proving unit)	AEP	08:18
7	Test isolated circuit to verify zero energy	AEP	08:20
8	Retest voltage tester on proving unit	AEP	08:22

9.9 Incident Report Form

Incident Report	Ref: INC-2026-004
-----------------	-------------------

Date & Time: 2026-10-10, 14:15	Category: Medical Treatment Case (MTC)
Location: Block 4, Row 12	Injured Person: Mechanical Fitter (Subcontractor X)
Description of Event:	During module alignment, the worker trapped his left index finger between the steel torque tube and the aluminum module frame. Sustained a severe laceration requiring 4 sutures at the local clinic.
Immediate Action:	First aid applied with pressure bandage to stop bleeding. Transported to clinic via site ambulance. Work area secured.
Initial Root Cause:	Failure to maintain clear hand placement (Line of Fire); failure of procurement to provide heavy-duty impact/cut gloves for this specific task.
Notification:	Client Notified: ☒ Yes (Within 4 hours) Lenders Notified: ☐ N/A (Does not meet 48h severity threshold).

9.10 Near Miss Report Form

Near Miss Report	Ref: NM-2026-081
Date & Time: 2026-10-12, 10:00	Location: Main Access Road
Description of Event:	A water bowser conducting dust suppression reversed without a spotter/banksman, narrowly missing a stationary light vehicle. Distance at halt was <0.5 meters.
Potential Consequence:	Property damage (vehicle crush), potential severe injury to light vehicle occupant.

Immediate Action Taken:	Removed driver from equipment. Confiscated site driving permit pending retraining.
Preventive Action:	Mandate reversing cameras on all heavy plant; reinforce policy that reversing without a banksman is a terminable offense.

9.11 EHS Monthly Report (Contents & Format)

Report Section	Metrics & Content Included
1. Executive Summary	High-level overview of HSE performance, major milestones achieved, significant incidents.
2. Lagging Indicators	Total Man-hours, Fatalities (O), LTIs, MTCs, FAls, LTIFR calculation, TRIFR calculation.
3. Leading Indicators	Near Misses reported, Safety Observations closed, TBTs conducted, PTW audits completed.
4. Environmental Data	Water usage (m^3), Waste generated (tons of Hazardous/Non-Haz), Dust monitor exceedances.
5. Social & Grievances	Number of grievances raised, resolved within SLA (14 days), outstanding issues, local hiring %.
6. CAPA Status	Open corrective actions, overdue actions, closed actions with verification evidence.

9.12 Pre-Task Risk Assessment (PTRA)

Task Step	Hazard Identified	Agreed Control Measures
-----------	-------------------	-------------------------

1. Unload PV Modules	Crush injuries / Dropped load	Use mechanical telehandler. Exclude personnel from the 5m drop zone. Taglines used.
2. Carry Modules	Back strain / Wind loading	2-person lift mandatory. Clear path of trip hazards. Do not carry if wind >10m/s.
3. Bolt to Structure	Pinch points / Sharp edges	Wear cut/impact gloves. Communicate placement timing loudly. Keep fingers out of bolt holes.
Crew Sign-off:	<i>We have discussed the hazards and agree to follow the controls.</i> (Signatures of 5 crew members)	

10. EHS Interfaces

The EHS department does not operate in a vacuum; it constantly interfaces—and occasionally conflicts—with other project functions.

- **With Construction:** The fundamental tension exists between schedule execution and safety compliance. The EHS Manager holds absolute Stop Work Authority. EHS approves the safety sections of all Method Statements prior to work commencing. To maintain checks and balances, Construction Supervisors act as PTW Issuers (requesting permission to work), while EHS Officers act as PTW Authorizers (validating the safety of the work), creating a deliberate friction that ensures risk is properly mitigated.
- **With Testing & Commissioning (T&C):** As the site transitions from civil/mechanical construction to an energized status, the hazard profile shifts dramatically. PTW control transitions from the Construction Manager to the Commissioning Manager. LOTO becomes strictly controlled under a formalized Commissioning isolation procedure, shifting from standard padlocks to highly complex Trapped Key Interlocks and permit-to-test protocols controlled by a dedicated Control Person (Safety).
- **With Contracts:** Subcontractor EHS violations are not merely recorded; they are penalized commercially. The EHS Manager issues formal Non-Conformance Reports (NCRs) that are linked to the subcontract agreements, allowing the Contracts department to withhold payments or apply Liquidated Damages (LDs) for systemic PPE failures, PTW breaches, or environmental spills.

- **With Client/IE/Lender:** The EHS team generates comprehensive Monthly EHS Reports detailing all KPIs, audit findings, and grievance logs. Lenders, driven by the Equator Principles and IFC requirements, will conduct rigorous quarterly or bi-annual site audits to verify that the ESMS is functioning as documented, not just existing on paper.
- **With Statutory Authorities:** The project interfaces heavily with the Uzbekistan Ministry of Employment and Labour Relations (the Labour Inspectorate) regarding working hour compliance, severe accident reporting, and worker welfare standards²⁸. Simultaneously, environmental monitoring data (PM10 dust levels, noise, waste manifests) must be submitted to the Ministry of Ecology, Environmental Protection and Climate Change to maintain State Ecological Expertise (SEE) compliance²⁵.

11. Common EHS Scenarios on Solar Projects

Scenario 1: Worker falls from module installation height

Immediate Response: A worker slips on the uneven terrain while installing modules on a steep incline and is left suspended in their fall restraint harness. Any witness immediately triggers the site emergency alarm and halts all local work. The local rescue team implements the WAH rescue plan, utilizing a mobile elevating work platform (MEWP) or rescue ladder to retrieve the suspended worker within 5 minutes. This rapid extraction is critical to prevent suspension trauma, where blood pools in the legs and causes cardiac arrest upon release. The worker is evaluated by the site medic and transported to the clinic. The area is quarantined, and a Bow-Tie investigation is initiated to determine if the slip was due to improper footwear, excessive wind, or rushing.

Scenario 2: Hot works start without a permit

Immediate Response: A GUARDIAN officer spots a subcontractor grinding steel without a fire watch, fire blankets, or a valid PTW. The officer exercises Stop Work Authority immediately, physically unplugging the grinder. The workers and their immediate supervisor are escorted to the site office and subjected to disciplinary action, which may include removal from the site. A safety stand-down is called for that specific subcontractor, requiring them to be re-inducted on PTW criticality before they are permitted to resume any work.

Scenario 3: Subcontractor brings unlicensed operator for a mobile crane

Immediate Response: While gate security and EHS induction checks should catch this, if an unlicensed operator is discovered manipulating a crane on-site, the crane is immediately red-tagged and shut down mid-operation (once the load is safely grounded). The operator is escorted off-site. The subcontractor receives a major NCR and a commercial penalty from the Contracts team. The equipment remains grounded until a legally licensed, third-party verified operator is deployed and their credentials are vetted by the EHS Manager.

Scenario 4: Transformer oil spill during installation

Immediate Response: During the filling of the 220kV transformer, a hose flange ruptures, spilling dielectric oil. The installation team immediately hits the emergency pump shutoff and deploys the local spill kit, using absorbent booms to corral the oil and prevent it from soaking

into uncompacted soil or reaching drainage channels. The VERDANT Environmental Officer is notified. Contaminated soil and saturated absorbents are excavated, placed in hazardous waste bags, and logged on the waste manifest for specialized disposal²⁵. The root cause (e.g., failed flange, lack of preventative maintenance on the pump) is investigated.

Scenario 5: Lender's EHS auditor finds systemic PTW non-compliance

Immediate Response: An external IFC auditor discovers that several excavation permits are signed but the shoring requirements are not implemented in the field. The EHS Manager immediately initiates a total site safety stand-down for civil works. An urgent Corrective Action Plan (CAPA) is drafted and submitted to the lender to prevent funding suspension. This CAPA will involve retraining all civil supervisors, implementing a digital PTW tracking system to prevent administrative bypasses, and increasing the number of GUARDIAN field officers to physically verify trench compliance before authorization is granted.

Scenario 6: Heat stress incident in July (Uzbekistan summer, 45°C+)

Immediate Response: A worker collapses from heat exhaustion. First aid is immediate: the worker is moved to an air-conditioned shaded area, their feet are elevated, heavy clothing is loosened, and oral rehydration salts (ORS) or IV fluids are administered by the site medic. Preventatively, the EHS Manager enforces strict SanPiN 0289-10 protocols¹⁶. This involves altering the entire project work schedule to early mornings and late evenings to avoid the peak heat of the day, enforcing mandatory 15-minute shaded rest breaks every hour, and mandating strict water consumption quotas tracked by supervisors.

Works cited

1. esms-toolkit-general-2025.pdf,
<https://www.ifc.org/content/dam/ifc/doc/2025/esms-toolkit-general-2025.pdf>
2. Solar Power Construction Safety Standards: A Comprehensive,
<https://vrenergy.vn/en/solar-power-construction-safety-standards-a-comprehensive-guide-to-iec-61730-international-best-practices/>
3. ISO 45001 Certification - SIS Certifications,
<https://www.siscertifications.com/en-my/iso-45001-certification/>
4. 6 Health and safety management - Detail - Solar Best Practices,
<https://solarbestpractices.com/guidelines/detail/health-and-safety-management>
5. Uzbekistan: 250MW Bukhara Solar & Battery Storage Project Part 5,
https://www.adb.org/sites/default/files/project-documents/57212/57212-001-iee-en_3.pdf
6. Nur Bukhara Solar PV - JICA,
https://www.jica.go.jp/english/about/policy/environment/id/asia/central/a_b_fi/uzbekistan/_icsFiles/fieldfile/2023/11/13/3.NUR_BUK_Vol_III_TA_v.3.0_FINAL_24AUGUST2023.pdf
7. The Failure of Reform in Uzbekistan - Department of Justice,
<https://www.justice.gov/file/277791-0/dl?inline=>
8. Eradication of Forced Labour - The Web site cannot be found,
https://www.files.ethz.ch/isn/44804/2007_General%20Survey-Forced%20labour

[%20Convention.pdf](#)

9. Uzbekistan EOR & PEO Services | NNRoad Global Compliance, <https://nnroad.com/services/employer-of-record-uzbekistan/>
10. Guidance note on employee grievance mechanisms - EBRD, https://www.ebrd.com/content/dam/ebrd_dxp/assets/pdfs/environment---sustainability/implement-performance-requirements/prs/pr2/Employee-grievance-mechanism.pdf
11. Human Rights Watch - Project Lifeline, <https://projectlifeline.us/wp-content/uploads/2020/08/2014-HRW-Report-Honduras.pdf>
12. Renewables grid integration project Environmental and Social, https://azerenerji.gov.az/site/assets/files/ESIA_Report_GOA%20Part_ENG.pdf
13. New Catalog Kirk Key | PDF - Scribd, <https://www.scribd.com/document/675428471/New-Catalog-Kirk-Key>
14. GAIL(India)Ltd.,PATA Petrochemical Complex | DOCX - Slideshare, <https://www.slideshare.net/slideshow/gailindiaLtdpata-petrochemical-complex/70528616>
15. 138kV Transmission Tower Guide: How to Evaluate & Choose Right, <https://electronics.alibaba.com/buyingguides/138kv-transmission-tower-guide-what-you-actually-need-to-know>
16. Occupational Heat Stress Rules — Uzbekistan, <https://heatrules.com/countries/uz/>
17. KMK 2.01.08-96 PDF - gostperevod, <https://gostperevod.com/kmk-2-01-08-96.html>
18. When Should Incident Reports Be Completed? Timelines, Legal, <https://www.accountablehq.com/post/when-should-incident-reports-be-completed-timelines-legal-requirements-and-best-practices>
19. DORA Incident Reporting: Timelines and Requirements - Legiscopes, <https://www.legiscopes.com/blog/dora-incident-reporting.html>
20. Cyber Incident Reporting Requirements & Notification Timelines for, <https://bpi.com/cyber-incident-reporting-requirements-notification-timelines-for-financial-institutions/>
21. World Bank Document, <https://documents1.worldbank.org/curated/en/099113002242320364/pdf/P175731041ae66020ba3c06555f9ab7012.pdf>
22. Content of fine PM 2.5 particles in Tashkent's air exceeds the norm, <https://kun.uz/en/news/2024/01/19/content-of-fine-pm-25-particles-in-tashkents-air-exceeds-the-norm-significantly>
23. BUKHARA WATER SUPPLY AND SEWERAGE PROJECT PHASE 1, <https://uzsuv.uz/media/uploads/2025/03/25/karaulbazar-sewerage-environmental-and-social-impact-assessment.pdf>
24. Environmental Impact Assessment UZB: Gas Transmission Network, https://www.adb.org/sites/default/files/project-documents/52322/52322-001-eia-en_10.pdf
25. Uzbekistan Introduces New Environmental Standards for Construction, <https://www.uzdaily.uz/en/uzbekistan-introduces-new-environmental-standards->

[for-construction/](#)

26. Environmental Protection | JSC “Thermal Power Plants”,
<https://tpp.uz/en/page/atrof-muitni-muofaza-qilis>
27. Initial Environmental Examination Uzbekistan,
<https://www.adb.org/sites/default/files/project-documents/51012/51012-003-iee-en.pdf>
28. Skills Development for a Modern Economy Project,
<https://www.gtai.de/resource/blob/612326/959109de502fc26d1d8d61f7c2b7cead/PRO20210211612286.pdf>