


TRUNK OPENER

DESCRIPTION


The trunk opener can be operated through the wireless remote control transmitter or lever. For models equipped with the smart key system, [see page BE-89](#)

► System Diagram ◀



025BE180TE

LAYOUT OF MAIN COMPONENTS



025BE181TE