


Position of Parts in Body



- H 1 Speaker (Front Door RH)
- H 2 Outer Rear View Mirror (RH)
- H 4 Power Window Regulator Motor (Front Passenger's Side)
- H 5 Door Lock Control SW
- H 6 Power Window SW (Front Passenger's Side)
- H 7 Courtesy Lamp (Front Door RH)
- H 8 Door Lock Assembly (Front Passenger's Side)

- I 1 Speaker (Front Door LH)
- I 3 Outer Rear View Mirror (LH)
- I 4 Power Window Regulator Motor (Front LH)
- I 5 Power Window Regulator Motor (Front LH)
- I 6 Courtesy Lamp (Front Door LH)
- I 7 Door Lock Assembly (Driver's Side)

- J 1 Power Window SW (Rear RH)
- J 3 Power Window Regulator Motor (Rear RH)
- J 5 Door Lock Assembly (Rear RH)

- K 1 Power Window SW (Rear LH)
- K 3 Power Window Regulator Motor (Rear LH)
- K 5 Door Lock Assembly (Rear LH)

- M 1 Power Window Master SW

- Q 1 Vanity Lamp SW (LH)
- Q 2 Vanity Lamp SW (RH)
- Q 3 Inner Rear View Mirror
- Q 5 Microphone (Navigation)
- Q 6 Overhead J/B
- Q 7 Vanity Lamp (LH)
- Q 8 Vanity Lamp (RH)
- Q 9 Room Lamp (Center)
- Q 10 Map Lamp (RH)
- Q 11 Map Lamp (LH)
- Q 12 Microphone (Navigation)
- Q 13 Sliding Roof Control ECU and Motor
























- S 1 License Plate Lamp (RH)
- S 2 Rear Combination Lamp (RH)
- S 3 Rear Combination Lamp (LH)
- S 4 License Plate Lamp (LH)
- S 5 Door Lock Assembly (Luggage)
- S 6 Luggage Compartment Door Lock Cylinder
- S 8 Luggage Compartment Door Lock Cylinder
- S 9 Luggage Electrical Key SW
- S 10 Turn Signal Lamp (Rear LH)
- S 11 Rear Combination Lamp (LH)
- S 12 Rear Combination Lamp (RH)
- S 13 Turn Signal Lamp (Rear RH)
- S 14 Electrical Key Oscillator (Outside Luggage Room)
- S 15 Junction Connector
- S 16 Junction Connector

- W 1 Door Outside Handle (Front RH)
- W 2 Electrical Key Oscillator (Front Door RH)

- X 1 Door Outside Handle (Front LH)
- X 2 Electrical Key Oscillator (Front Door LH)

- f 1 Speed Sensor (Rear LH)
- g 1 Speed Sensor (Rear RH)

Position of Parts in Body



Position of Parts in Body

