




- N 3 Front Seat Inner Belt (Driver's Side)
- O 3 Front Seat Inner Belt (Front Passenger's Side)
- O 4 Occupant Classification ECU
- Y 1 Side Airbag Squib (RH)
- Z 1 Side Airbag Squib (LH)
- d 1 Occupant Classification ECU
- d 2 Occupant Classification Sensor (Front LH)
- d 3 Occupant Classification Sensor (Rear LH)
- d 4 Occupant Classification Sensor (Front RH)
- d 5 Occupant Classification Sensor (Rear RH)

Position of Parts in Seat <w/o Power Seat>

